


# Smart Light Switch

## Quick Installation Guide




<b>1. Installation .....</b>	<b>3</b>
<b>1.1. Installation.....</b>	<b>3</b>
1.1.1. Interface and wiring diagram.....	3
1.1.2. Specification .....	4
1.1.3. Installation procedure.....	4
<b>2. Federal Communication Commission Interference Statement .....</b>	<b>6</b>

# 1. Installation


## 1.1. Installation

### 1.1.1. Interface and wiring diagram

The button at the front of Light Switch allows you to change the on/off status of light.




At the back of Light Switch, there are 6 holes, 3 at each side. Please make sure that you connect the right wiring to make it work.



There is one installation notice at the back of Light Switch.

Please keep aware of the wiring to make it work.




### 1.1.2.Specification


Type	Voltage	Frequency	Loading range
Single Switch	AC 100~240v	50/60 Hz	< 500VA
Dual Switch	AC 100~240v	50/60 Hz	< 500VA each port

### 1.1.3.Installation procedure

- Make sure you have already add the Light Switch.
- Turn off the main switch of your house.
- Put on insulating gloves and make sure the environment is dry.
- Remove the original wall switch.
- Trim the electrical wire in the wall to around 10cm long and the copper part to


10mm long. (Check notice at the back  )

- Insert the electrical wire into the terminal at the back of Light Switch. Please make sure the copper part really fix in it and should not be seen.





Correct




Wrong

- g. Turn on the main switch of your home.
- h. Wait 1 minute.  
Manual press the switch to test to see if the light can turn on and off. (Turn on time will be around 0.5~2 seconds, depends on different lighting fixture design.)
- i. Fix Light Switch in the wall.

You house may or may not have the metal box. (This is not including in our product.)

2. Fix main body in the wall and click the front panel to finish installation.



1. This is main body. Please finish the wiring and fix it in the wall.

## 2. Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### **FCC Caution:**

- Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.
- This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

### **Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.