


User Manual

Instruction of main controller:



The control box assembly is mounted on the back of the bed or the bed frame by five screw holes, and then the main control box is rotatably mounted to the fixed plate. The connection between it and other components is as follows:



First, the connection between the control box component and the power adapter is completed.



Then complete the mating pairing of the linear motor assembly and the control box assembly.



Pairing use:

Press the reset button 5s on the main controller, and press any key on the remote, controller automatically search and pair for use.

Functions of each button:

- 1: leg motor socket
- 2: back motor socket
- 3: reset button: click to reset the motor. Long press for 5 seconds to turn on the remote control pairing function
- 4: power socket
- 5: wireless signal indicator light: the indicator light flashes when the main control board receives the signal of the remote control, and it will always light up after the pairing of the remote control.
- 6: leg motor indicator light: the leg motor indicator light is always on when the leg motor socket is inserted into the motor in the main control board.
- 7: back motor indicator light: the back motor indicator light is always on when the motor socket on the back of the main control board is inserted into the motor.
- 8: power indicator: turn on the power, the power indicator is long on.

NOTE:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.