


尺寸:87\*55mm

产品说明书

—Product description—




YYK-Q29

半入耳蓝牙耳机

产品规格

蓝牙版本:V5.4
通话时间:5-8小时
音乐播放:5-8小时
待机时间:90小时
通信距离:≥10m
耳机充电时间:约1.5小时
耳机电池容量:40mAh
充电仓电池容量:180mAh
频率范围:2.400GHz-2.480GHz
支持协议:A2DP/AVDTP/AVRCP/RFCOMM/HFP/HSP/SPP/HID

多功能键



暂停/播放:单击MFB键
上一曲:双击L边MFB键
下一曲:双击R边MFB键
音量加:三击L边MFB键
音量减:三击R边MFB键
接听电话:单击MFB键
挂断电话:单击MFB键
来电拒接:长按MFB键1秒
取消通话:单击MFB键
呼叫Siri:长按3秒右MFB键
取消Siri:长按3秒右边MFB键

开机关机

1.初次开始使用的情况下,当耳机从充电仓里取出耳机就会自动开机。  
放回充电仓耳机就会开始充电并自动关机。  
2.当耳机不使用时,放回充电仓自动关机。

如何配对

1.从充电仓拿出开机  
2.耳机自动配对  
3.打开手机/平板的设置---蓝牙---打开蓝牙---搜索---YYK-Q29---配对/连接---播放音乐。

电脑/手提电脑配对的方法

打开电脑设置-设备-蓝牙和其他设备-开启蓝牙--添加蓝牙或其他设备-搜索蓝牙设备YYK-Q29-配对/连接-播放音乐。  
注意:如果电脑没有蓝牙,请插入蓝牙适配器,下载蓝牙驱动后再正常使用。

如何给耳机充电

1.把耳机放入充电仓内,耳机就会自动关机然后开始充电,充电仓亮起,说明充电仓正在给耳机充电。  
2.耳机充电时红灯常亮,充满灭灯。

给充电仓充电

请使用手机适配器给充电仓充电,可以使用电脑Type-c线或者其他Type-c接口的充电器进行充电。

安全预防


高质量的耳机,为了延长使用寿命,请参考以下说明:  
1.请本品远离高温、高湿、腐蚀环境。  
2.请防止本品被撞击、跌落、弯曲、浸泡等。  
3.请不要将耳机或者充电器。  
4.请不要让本品一超过度充电,这样降低本品的使用寿命。  
5.如果它引任何不适感或者疼痛,请停止使用本品。  
6.使用由受监督的制造商认证的DC 5V-1A适配器。  
反复充电和放电耳机可能会导致电池性能随时间降低,这对所有可充电电子产品来说都是正常的。

产品包装内有

1.蓝牙耳机2个  
2.充电座1个  
3.Type-c充电线1条  
4.说明书1本

User Manual

—Product description—




YYK-Q29

Half-in-ear Wireless headphones

Product specifications

wireless version: V5.4
Talk time: 5-8 hours
Music playing: 5-8 hours
Standby time: 90 hours
Communication distance:≥10m
Charging time of headset: about 1.5hour
Headset battery capacity: 40mAh
Battery capacity of charging chamber: 180mAh
Frequency range: 2.400GHz-2.480GHz
Support agreement:A2DP/AVDTP/AVRCP/RFCOMM/HFP/HSP/ SPP/HID

multiple use key



Pause/Play: Click the MFB key
Previous: Double click the L-side MFB key
Next: Double click the R-side MFB key
Volume plus: Strike the L-side MFB key three times
Volume reduction: Strike the R-side MFB key three times
Answer the call: Click the MFB key
Hang up: Click the MFB key
Call rejection: Hold down the MFB key for 1 second
Cancel a call: Click the MFB key
Call Siri: Press and hold the right MFB button for 3 seconds
Cancel Siri: Press and hold the right MFB button for 3 seconds

Power on/off

1. When the headset is taken out of the charging chamber for the first timeThe headset will turn on automatically.  
Put the headset back in the charging chamber and it will start charging and automatically shut down.  
2. When the headset is not in use, put it back into the charging chamber and turn it off automatically.

How to pair

1. Take out the charging chamber to start the machine  
2. Automatic headset pairing  
3. Open the settings of mobile phone/tablet --- Bluetooth --- Open Bluetooth --- Search--- YYK-Q29 --- pairing/connecting --- playing music.

Computer/laptop pairing method

Open Computer Settings - Devices - Bluetooth and Other devices - Enable Bluetooth - Add Bluetooth Or other devices - Search for Bluetooth device YYK-Q29- Pair/Connect - Play music.  
Note: If the computer does not have Bluetooth, please plug in the Bluetooth adapter and download the Bluetooth driver  
Then normal use.

How to charge the headset

1. Put the headset into the charging compartment, the headset will automatically shut down and start charging. The charging compartment lights up, indicating that the charging compartment is charging the headset.  
2. When the headset is charging, the red light is steady on and the lamp is off when it is full.

Charge the charging chamber

Please use the mobile phone adapter to charge the charging chamber. You can use the computer Type-c cableOr other chargers with Type-c interface.

Safety precautions

For high-quality earphones, please refer to the following instructions to prolong the service life:  
1. Please keep away from high temperature, high humidity and corrosive environment.  
2. Please prevent the product from being hit, dropped, bent, soaked, etc.  
3. Please do not remove the headset or charging stand.  
4. Please do not allow the product to be overcharged all the time, so as to reduce the service life of the product.  
5. If it causes any discomfort or pain, please stop using this product.  
6. Use a DC 5V-1A adapter certified by a regulated manufacturer.  
Repeated charging and discharging of the headset will cause the battery performance to decrease over time, which will affect all rechargeable Electronic products are normal.

There are

1. Two Bluetooth headsets  
2. One charging base  
3. One Type-c charging line  
4. 1 manual

FCC Warning

15.19 Labeling requirements.  
This device complies with part 15 of the FCC Rules.  
Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.  
15.21 Information to user.  
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
15.105 Information to the user.  
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-Reorient or relocate the receiving antenna.  
-Increase the separation between the equipment and receiver.  
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-Consult the dealer or an experienced radio/TV technician for help.

FCC RF Radiation Exposure Statement:

1.This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.  
2.This equipment complies with RF radiation exposure limits set forth for an uncontrolled environment.  
This equipment should be installed and operated with minimum distance 5mm between the radiator and your body.