

FCC ID: 2AP4B -V5

True Wireless Stereo Earphone

V5



HIGH FIDELITY SOUND

Combining dynamic speakers for wireless music enjoyment


In the box


- 1 V5 Wireless Earphones
- 2 On-the-go Charging Case
- 3 3 Pairs of Silicone Eartips(Size S/M/L),
- 3 3 Pairs of Earwings(Size S/M/L),
- 4 Micro-USB Cable
- 5 User Manual

Functions


- 1 MFB (multifunction button)

2 Indicator light


- 4 Charging Case indicator



- 3 Charging contact point


- 5 Micro USB charging port



- 2

How to wear your TWS Earphones

Step 1



Step 2




Charging (case)

To charge the charging box, simply connect it to the USB power supply through the micro USB cable. When charging, the LED lights in front of the charging box will flash. After finished charging, the four LED lights will remain on for 1 minute and then all will be turned off. A fully charged charging case can support two earphones recharging approximately four times.

Electronic indicator light


25% of Battery capacity or less - 1/4 LED light
50% of Battery capacity or less - 2/4 LED lights
75% of Battery capacity or less - 3/4 LED lights
100% of Battery capacity or less - 4/4 LED lights



Charging (earphones)

To charge the earphones, simply place them into the charging case(Ensure two earphones are placed in corresponding slot). The LED lights on both earphones turning red indicate that earphones are under charging status and then will be shut off when fully charged.

Note: Please charge the earphones and the charging case once at least every 3 months if you do not use the earbuds for a long time. Please disconnect the charger in time when the charging case is fully charged.



How to Turn On/Off

Turn on:

Method 1: Take both earbuds out of the charging case,they will turn on and connect with each other automatically .
Method 2: When the earbuds is power off, press and hold the multi-function button on either earbud for 3 seconds. (LED lights on both earbuds will keep blue for 2 seconds)

5

Turn off:

Method 1: Put the earbuds back into the charging case, they will turn off automatically.
Method 2: When the earbuds are power on, press and hold the multi-function button on either earbud for 5 seconds. (LED lights on both earbuds will keep red for 4 seconds)

Note: If you turn one of the earphones off while both earphones are paired with your Bluetooth enabled device, another one will turn off at the same time.

How to Pair
Twins Earbuds Mode

1. Take both earbuds out of the charging case, they will power on and connect with each other automatically (The LED lights on earphones flash blue and voice prompt says"left channel"&"right channel"
2. Enable Bluetooth on your device and select "V5" from list to connect.You will hear voice prompt"pairing successfully" once connected.
3.Once the earbuds paired with your device manually for the first time as described above, they could pair with this device automatically each time in the future as soon as you take them out from charging case.Note: If you hear voice prompt "Low battery"from one of the earphones, another one may have some battery left in fact.You can put the low battery one back into charging case for charging and use another one as Mono Earbud Mode.

Mono Earbud Mode

Mono mode for Right earbud:

Take the right earbud out of the charging case, it will power on and enter pairing mode automatically.Enable Bluetooth on your device and choose "V5" on the list to connect. Next time you take the right earphone and it will be still used as a mono channel.When the left and right earphones are taken out together, the two earphones will automatically be paired to used as binaural stereo earphones.

6

Mono mode for
left earbud:

Take the left earbud out of the charging case, it will power on automatically. Enable Bluetooth on your device and search for "V5 L", tap to connect it.Next time you take the left earphone and it will be still used as a mono channel.When the left and right earphones are taken out together, the two ears will automatically be paired to used as binaural stereo earphones.

Remark: How to Reset Pairing Mode

If the L side earphone can't connect with R side or only one side works, take both sides earphones into charging case firstly, then take out to see if works well.If not please handle according to the following operation method.

When the earphones are under charging state, long press MFB for 5 seconds (L or R side) until two earbuds indicating purple LED lights,it means reset successfully.

Controls

Play/Pause music	Press either earbud MFB for once
Volume up	Quick double-press the MFB on left earbud
Volume Down	Quick triple-press the MFB on left earbud
Next Track	Quick double-press MFB on right earbud
Previous Track	Quick triple-press MFB on right earbud
Answer/End a Call	Press either earbud MFB for once
Reject an incoming call	Press and hold either earbud MFB for 2 seconds When there is an incoming call
Activate Siri	Press and hold either earbud MFB for 2 seconds until hear voice prompt "toot"

7

Specification

Bluetooth version	V5.0
Music paly time	3 hours
Talk time	3 hours
Standby time	40 hours
Effective distance	Up to 3.6ft/12m
Bluetooth profiles	HFP1.7/A2DP1.3/ AVRCP1.5
Driver	10mm
Sound pressure level	98±3dB
Frequency response	20Hz---20 KHz
Battery of headset	50mAH Li-polymer Battery
Charging voltage of headset	5V
Charging time of headset	1.5hours
Battery of box	470 mAH Li-polymer Battery
Charging voltage of box	5V
Charging time of box	1.5hours
Earphone weight	7g x 2pcs
Charging box weight	50g

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions,may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which thereceiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference
- (2) This device must accept any interference received, including interference that may cause undesired operation

8