




<h1>Truly Wireless Open Ear Headphones</h1> <p>OPENEAR Arco</p> <p>User Manual</p>	<h3>Headphones</h3> 	<h3>Specifications</h3> <p>Model: OPENEAR Arco Type: Truly Wireless Open Ear Headphones Version: V5.4 Connection: ≈10m Earbud Play Time: ≥5H (80% volume) Earbud Charging: 1H Case Charge Earbud: 7 Times Case Charging: 1.5H Charging Voltage: DC 5V</p>	<h3>How to Wear</h3> <p>Put the earhook behind the ear until it fits your ear.</p>  <h3>Battery Level Notification</h3> <p>Automatically announce the real-time battery level of the headphones after power on. Battery 100%-70%: Prompts: battery high. Battery 69%-40%: Prompts: battery medium. Battery 39%-10%: Prompts: battery low.</p>	<h3>Operations</h3> <h4>Power On/Off</h4> <p>The earbuds are automatically power on when opening case. Prompt: power on pairing; The earbuds turn off when placed into the charging case and closed the lid. Or press and hold the button on the earbuds for 5 sec. Prompt: power off.</p> <h4>BT Connection</h4> <p>Select "OPENEAR Arco" in BT menu to connect. Prompt: connected.</p> <h4>Two Sound Modes</h4> <p>The earbuds is built-in 2 different sound modes . In indoor mode, you will hear more bass effects. In outdoor mode, you will get higher volume. The default mode is indoor mode. Touch 4x of any earbuds to switch from indoor mode to outdoor mode.</p>
<p>Previous/Next Track Previous Track: Touch 3x of Left earbud. Next Track: Touch 3x of Right earbud.</p> <p>Volume Up/Down Volume Up: Touch 2x of Right earbud. Volume Down: Touch 2x of Left earbud.</p> <p>Activate Voice Command Activate Voice Command: Touch 3s of any earbuds.</p> <p>Play/Pause Music Touch 1x of any earbuds.</p> <p>Answer/Hang Up/Reject A Call Answer/Hang Up A Call: Touch 1x of any earbuds. Reject A Call: Touch 1.5s of any earbuds.</p>	<p>Low Battery When battery is lower than 20%, prompt: battery low.</p> <p>Earbud Charging Place the earbuds into the charging case and close the lid. The green LED light on the earbud is on when charging. White LED is on after fully charged.</p> <p>Case Charging Please use DC 5V adapter for charging. White LED is on during charging. The LED is off when fully charged.</p> 	<p>Attentions</p> <ol style="list-style-type: none"> 1. Listening to loud music for a long time may cause discomfort, please use medium volume if possible. Do not use high volume for long periods of time. 2. Using headphones will affect your perception of the surrounding environment. Pay more attention when using headphones. 3. Do not remove or modify the headphones, as this may cause damage or burn out. 4. Do not throw, twist or put them into a fire. 5. Keep it away from fire, hydration and high pressure equipment. 6. Not suitable for children under 10-year-old containing small parts. 7. Do not classify it as household waste. Please send it to the local electrical equipment recycling station. <p>Note: The company does not assume any responsibility for the loss of personal property caused by the violation of the above warnings.</p>	<p>FCC Warning Statement</p> <p>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. <p>FCC Radiation Exposure Statement The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p> <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:</p> <p>(1) This device may not cause harmful interference.</p> <p>(2) This device must accept any interference received, including interference that may cause undesired operation.</p>	