



Operations of Remote Control and Cars

As shown in the figure, operate the "Forward/backward" lever, the remote control car forward/backward.




As shown in the figure, conduct combined rocker operation of "Forward + Left / Right turn", the remote control car turns to the front left/turns to the front right.



As shown in the figure, operate the "Left/Right turn", the remote control car left/right rotation.




As shown in the figure, operate the "Side row key", the remote control car upper left/lower right/upper right/lower left side row.



As shown in the figure, operate the "Left horizontal move/right horizontal move" key, the remote control car moves to the left/right horizontally.




As shown in the figure, conduct combined rocker operation of "Backward + Left/Right turn", the remote control car turns to the back left/turns to the back right.



As shown in the figure, operate the "Light control" key, the remote control car opening/closing of the light effect.



As shown in the figure, operate the "One-key demonstration" key, the remote control car automatic stunt demonstration.



Instructions

The toy battery charger should be checked before use to prevent damage to wires and other components. If there is damage, it must be repaired before use.

General Fault Handling

| Symptoms | Fault cause | Treatment method |
|---|---|--|
| The vehicle cannot be operated | 1. The remote control is not connected or the remote control car switch is not on. 2. The battery is not properly installed. 3. The rechargeable battery is weak. | 1. Open the car switch, contact the remote control again. 2. Properly load the battery into the remote control and the car. 3. The car battery is charged. |
| The vehicle is not controlled and the distance is close by remote control | 1. Remote control or car battery, lack of electricity. 2. There may be a source of disturbance near the site. | 1. Replace the battery in your remote control or recharge your car battery. 2. Replace the site. |
| Abnormal protection | When the function of the remote control vehicle is hindered by external forces or the power is insufficient, circuit battery short circuit. | Re-turn on the power switch or take out the battery and reload it after it is powered off. |

To consumers

1. When playing with remote control cars indoors, please be careful not to damage furniture or glass.
2. Please play in a safe place outdoors. Don't play with remote control cars on the road and in crowds, so as to avoid danger.
3. When you hear thunder when playing in a remote control car outdoors, you should stop playing immediately.
4. When the wheels rotate, don't stretch your hands close to avoid injury, and don't get involved in hair, clothes, etc.
5. Do not drive the remote control car at people.
6. Do not throw or collide the remote control car.
7. Keep away from fire sources and high temperatures when placing remote control vehicles.
8. This car uses complex electronic circuits and a large number of meta-accessories. Please do not disassemble or modify the circuit board at will.
9. When the remote control car is covered with dirt and dust after playing, it must be gently wiped with a wet cloth.
10. Don't put the toy in water, it will damage the electronic components.



WARNING:

The contained widgets are at risk of suffocation and are not suitable for children ages 3 and under to play with. Adults must be present when using them for supervision and guidance. This manual contains important information, which cannot be discarded for inquiry.

FCCID: 2AP5E-JYS2900

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Toy RC Xtreme Wall Climber JYS2018

Alloy Spider Car Instruction Manual

Thank you for using our products. In order to get a better understanding of this product, Please read the following instructions carefully before using them, which will bring you a different sense of operating experience.

Attention

- Electric control product: This product is suitable for 6 years old and above. It is assembled/charged by adults and then played by children.
- Please use the product under the supervision of adults. Please do not dismantle or modify the product without authorization. Any modification may cause the product to be unable to be used normally.



Precautions for Use

1. The toy car uses a 7.4V rechargeable lithium battery; the remote controller uses 2X1.5V "AA" unchargeable batteries.
2. Battery removal and loading, should be carried out correctly according to the polarity and voltage in the toy battery box;
3. Uncharged battery not rechargeable;
4. The rechargeable battery must be charged under adult supervision;
5. The rechargeable battery should be taken out of the toy before charging;
6. Different types of batteries or old and new batteries can't be used in mix;
7. The car body must use the original configuration of battery; And the original USB cable must be used to charge the battery;
8. The run out of battery should be removed from the toys; If you haven't used it for a long time, please remove the toy's battery.
9. The power terminal shall not be short-circuited;
10. Use a screwdriver turned on the remote control battery cover screw, across the electrodes in the correct polarity into the battery, use a screwdriver on the battery cover screw drive at the end of the screw, the battery plug wire connected to the body the power cord in the correct polarity;
11. Repair and maintenance: this product is a plastic, hardware and electronic components, shall not enter the water or placed in a humid environment or use for a long time, regularly check the wires, plugs, casing and other parts for defects and found defects should stop using, and restored.

2.4G Automatic Code Matching Specification


1. The remote controller is equipped with a battery, the indicator of the remote controller starts flashing, and the remote control car is equipped with a battery to open the switch and starts to enter the connection state. When the connection is successful, the indicator of the remote control goes out. Note: Please repeat the above operation if the connection is unsuccessful.
2. Each remote controller can only be connected with one remote control car. When the connection is successful, each car will not interfere with each other. Note: When multiple cars are used at the same time, the connections can be opened in turn.
3. When the remote controller is unsuccessful in code alignment, it will go to sleep after 30 seconds. When the code alignment is successful, it will go to sleep after 300 seconds without operation, and any key will wake up.
4. When it is necessary to pair other remote controllers or remote control cars of the same model, it is necessary to take out the battery of the remote controller and turn off the power switch of the remote control car before re-pairing.

Description to the Functions of Remote Control




How to Recharge

1. This 7.4V lithium battery is new, before playing please charge the battery.
2. Plug the battery wire plug into the charger plug according to the correct positive and negative connection, and then plug the charging cable into the socket to charge.
3. It takes 2-3 hour to fully charge the battery. Charging plug with indicator light, red light on when charging, light off when full. Please don't overcharge, Charging for a long time will not increase the power.
4. Check toys and batteries regularly. If accessories, batteries, charging cables, etc. are damaged, stop using them immediately. After repair or renewal, can continue to use.



How to Install Batteries

1. Remote controller
(1) Open the battery cover of the remote control and load the 1.5 V "AA" battery according to the positive and negative poles in the battery bin of the remote control compartment.
(2) Cover the battery box and lock the screws.
2. Remote control car
(1) Open the battery cover under the car and connect the rechargeable battery to the power outlet and load it into the bottom of the car.
(2) Cover the battery box and lock the screws.



FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

*** RF warning for Portable device:**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

IC Caution.

CAN ICES-003(B) / NMB-003(B)

RSS-Gen Issue 3 December 2010" & "CNR-Gen 3e édition Décembre 2010:

- English:

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

- French:

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.