

SYLVANIA

 **Retro Wireless Speaker**

SP563-BLACK/BLUE/PINK




SYLVANIA is a registered trademark of OSRAM Sylvania Inc. used under license.


Thank you for purchasing this product. Please read this manual carefully, and save it for future reference.

Device Overview

Front Panel



Back Panel



1. Power ON/OFF Switch
2. LED Indicator
3. AUX in Port
4. Micro USB Charging Port
5. Mode Button (Change mode: Bluetooth, FM Radio, Aux-In)
6. FM Radio Antenna

Included In the Box

- | | |
|------------------------------|-----|
| 1. Speaker | 1pc |
| 2. Micro- USB Charging Cable | 1pc |
| 3. 3.5 mm Audio Cable | 1pc |
| 4. User Manual | 1pc |
| 5. Warranty Card | 1pc |

Specifications

Speaker Driver: 3"
Bluetooth Version : 4.1
Bluetooth Range: 33ft (10m)
FM: 87.5 ~108.0MHZ
Battery: 1200mah rechargeable lithium battery
Charging: DC 5V = 1 A

Device Operation

Charging the Speaker

Attach the small connector of the supplied micro-USB charging cable to the micro-USB charging port on the back of the speaker. Attach the other connector to the USB port on your computer, a USB charging device, or a **5V USB Adapter** (*not included*) and plug into a wall socket.

The charging LED indicator will turn **RED** while charging and turn off when the speaker is fully charged.

- Note: - Before moving or installing this product, make sure the Power switch of the unit is in OFF position.
- Disconnect the USB cable from the speaker when unused for long periods of time.

Powering ON/OFF

Turn the speaker ON by moving the **[POWER]** switch to the ON position.

Turn the speaker OFF by moving the **[POWER]** switch to the OFF position.

Bluetooth Mode

1. Turn the speaker ON by moving the **[POWER]** switch to the ON position. A tone will be heard and the speaker will turn on in FM radio mode. Press the **[MODE]** button to switch modes. When the speaker is in Bluetooth pairing mode, the LED indicator will quickly flash **GREEN**.
2. Set your mobile device to search for Bluetooth devices. When it appears, select **Sylvania SP563** from the list of found devices.

3. Once successfully paired, a tone will be heard and the LED indicator will slowly flash **GREEN**.

Note: - Playback is controlled through your connected device, volume adjustment can be controlled with the volume knob.

- After the unit has paired and connected, it will re-connect automatically when the unit is powered on and the device is in range.

Aux-In Mode

Attach one connector of the supplied 3.5mm audio cable to the Aux in port the back of the speaker, Attach the other connector to the headphone jack on your media-playing device.

When plugged in, the speaker will automatically switch to AUX mode, and the LED indicator will turn solid RED. Playback is controlled through your connected device. Volume adjustment can still be controlled with the volume knob on the front of the speaker.

Using the FM Radio

For best reception, extend the FM radio antenna. You may need to adjust or position the antenna for certain stations.

- When in FM radio mode, the LED indicator will flash RED.
- Use the FM tuner dial on the front of the speaker to select a radio station.

Note: - When powering on, it will automatically go to FM Radio mode.

- Control the volume through the volume knob.

LED Status

Green Solid	Powering on
Green flash quickly	bluetooth waiting for pairing
Green flash slowly	Bluetooth paired
Red flash slowly	FM radio mode
Red solid	Aux-In mode / charging

TROUBLE SHOOTING GUIDE

No power	- Make sure the power switch is set in the "ON" position. - Speaker needs to be charged
No sound	- Check whether the volume is set at minimum level.
Unit doesn't connect to device	- Speaker needs to be connected/re-paired to device

For service assistance and product information, please call: 1-800-968-9853.
Curtis International Ltd.
7045 BECKETT DRIVE, UNIT 15, MISSISSAUGA, ON, L5S 2A3
www.curtisint.com

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.