


## Congratulations on your recent purchase of the RGB Drop lighting Product.

### Getting Started:

1. Read all enclosed Safety Instructions and cord tags before starting.
2. Plug your RGB Drop light string(s) into a power source.

### Using the Remote Control:



**Solid Colors:** Locate the color on the remote control and simply push that button to set all the lights the same color.

- W = White
- R = Red
- G = Green
- B = Blue

**Mode:** Press the Mode buttons in order to select the function that you would like. This entails a multitude of options for you to select from.

**Auto:** Select this button in order to have all 358 different functions cycle through automatically

**Color Cycle:** Press and hold down the AUTO button in order to have lights flash through the colors.

**Speed :** Press the "+" or "-" in order to select the desired speed of the function

 : Press this button in order to dim the light string

 : Press this button in order to make the light string brighter

 : Press button to turn on and off. Your lights will automatically remember the last function and turn back on in the same function/color scheme.

 : If you have multiple light strings and want to control each string with a separate remote controller, hold the lock button down for 5 seconds (light string will flash). To cancel, hold the lock button down for 5 seconds (light string will flash) in order to use one remote controller for additional light strings.

 : This button is not applicable to this model.

This device complies with Part 15 of the FCC and Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- 1) L'appareil ne doit pas produire de brouillage;
- 2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

FCC NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver
- Connect the equipment into an outlet on a circuit that is different from that to which the received is connected
- Consult the dealer or an experienced radio/TV technician for help.

Model No. Remote Controller-A 02/19

3V DC

Shan Dong Neon King Electronics Co., Ltd.

Weishan County, JINING CITY, Shangdong 277600

MADE IN CHINA