


©Smart4u



SS1

蓝牙滑雪头盔

Bluetooth Ski Helmet


快速入门指南 & 保修卡

Quick Start Guide & Warranty Card

中

EN

www.smart4u.ai



注：按任意键（+ / - / ⏪）均可接听电话。

开 / 关机

[开机] 长按开关机键  (约 3s)，直至听到开机语音提示， 指示灯亮起，开机成功。

[关机] 长按开关机键  (约 3s)，直至听到关机语音提示， 指示灯熄灭，关机成功。

充电

插上 USB 电源，指示灯  闪烁，进入充电状态；充满后指示灯  自动熄灭。

蓝牙连接

关机状态下，长按产品 **①** 键直到听到“Pairing”后松开，打开手机蓝牙并扫描到“Helmet phone-SS”设备，点击进行连接，连接成功后，会提示“Connected”。

技术规格

声音：麦克风 -35dB, D27mmx2 32Ω 高保真扬声器

蓝牙：BT4.2, 最大 6mW

蓝牙距离：最大 10 米

充电接口：Micro USB

电话

在蓝牙耳机连接上手机时，即可通过头盔主控的任意键接听电话。



接听电话：短按任意键 (+/-/①)

拒接 / 挂断电话：

长按任意键 > 1.3 秒 (+/-/①)

电气参数：DC 5V—1A

电池：3.7V/300mAh, 充电约 2 小时

续航时间：通话时长最大 300 分钟，连接时长最长 15 小时


使用温度：建议在 -20°C ~ 50°C 环境下使用电子功能



错误



错误



正确



下载来啊滑雪 App

Smart4u 保修明细

一、质保细则

1. 以下若有与国家政策不符或遗漏之处，以国家政策为准。
2. 本产品自购买之日起因产品质量问题免费保修一年，在确保商品完好的情况下 15 天内包换。
3. 本公司对产品的其他配置（例如：快速入门指南及包装等）不承担质保责任。

二、保修说明

您的保修服务仅限于正常使用下有效。非本产品本身品质原因造成的损坏及属下列情况之一产品，不实行质保。但可以实行收费修理：

1. 超过质保有效期；
2. 无质保凭证及有效发票的，但能够证明该产品在质保有效期内的除外；
3. 质保凭证上的内容与商品实物不符或者涂改的；
4. 未按产品使用说明书要求使用、维护、保养而造成的损坏；
5. 非本公司授权的服务店拆动造成损坏的；
6. 因不可抗力造成的损坏；
7. 产品自然磨损（例如：外壳、按键、油漆、附件等）；
8. 非本公司原因造成的故障、缺陷或瑕疵。

Smart4u 官方网站：www.smart4u.ai

执行标准：Q/SSD1077-2018

产品中有害物质的名称及含量

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr6+)	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
PCB	X	X	O	O	O	O
元器件 (含模块)	X	O	O	O	O	O
金属结构件	O	O	O	O	O	O
塑胶结构件	O	O	O	O	O	O
纸质配件	O	O	O	O	O	O
塑料包装件	O	O	O	O	O	O

本表格依据 SJ/T 11364 的规定编制。

O: 表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。


X: 表示有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求。



本产品的“环保使用期限”为 10 年，其标识如左图所示。充电器等可更换部件的环保使用期限可能与产品的环保使用期限不同。只有在本使用说明书所属的正常情况下使用本产品时，“环保使用期限”才有效。

警示

- 1. 禁止拆解，撞击挤压或投入火中；
- 2. 请勿置于高温，潮湿或腐蚀环境中；
- 3. 不可让金属品接触或短路电正极；
- 4. 若出现严重膨胀，请勿继续使用；
- 5. 电池浸水后禁止使用。



Press any button “+ / - / ⏪” to answer the phone.

Power On/Off

Hold the  button for 3 seconds until you hear the power on voice prompt and the indicator light turns on.

Hold the  button for 3 seconds until you hear the power off voice prompt and the indicator light turns off.

Charging

Plug the USB charger in. The indicator light will blink when charging. The indicator light will turn off automatically when fully charged.

Bluetooth Paring

1. When helmet is powered off, hold press the  button at the back of the product until you hear "Pairing".
2. Switch on Bluetooth of your phone and scan for the "Helmetphone-SS" device.
3. Click to connect. A voice prompt "Connected" will be heard from the speakers when the connection is completed.

One Button Answer



Once the Bluetooth Headset is connected to your mobile phone, press any button on the helmet to answer the phone call.

Answer Phone Call: press any key (+/-/ )

Decline/End Call: hold down any key for >1.3s (+/-/ )

Technical Specifications

Voice: Mic-35dB, D27mm x2 32Ω

Charging port : Micro USB, DC 5V/1A, charging time Approx. 2hrs


RF: BT4.2 Max. 6mW

Battery capacity : 3.7V/300mAh, 5 hours for walkie-talkie, 15 hours for standby only

Bluetooth : Max. 10m if no obstruction to Bluetooth

Usage temperature: -20°C ~ 50°C is recommended for electronic functions


Intercom range : No distance limit by mobile data



Incorrect



Incorrect



Correct



Download the App

SSD's Warranty Details

I. Warranty Details

1. If there is any discrepancy or omission between the following and any national policy, the national policy shall prevail.
2. The warranty time is 1 year after purchase. Any quality problem can be maintained for free or it can be replaced within 15 days after purchase if re-sale is available.
3. SSD bears no responsibility for warranty over other product components. i.e, the Quick Start Guide, Warranty Card, etc.

II. Warranty Description

The warranty services are only valid under conditions of normal use. In case of any damage caused by reasons unrelated to product quality or any of the following circumstances, warranty services shall not be provided. But paid maintenance may be carried out:

1. The warranty period expires;
2. There is no valid invoice or warranty certificate, unless it can be otherwise proved that the product is within the validity date of the warranty period;
3. The details on the warranty certificate do not match the specific goods or are altered;
4. Any damage caused by use, maintenance or care that contravenes the guidelines of the product's instruction manual;
5. Any damage caused due to disassembly by non- SSD designated service centers;
6. Any damage caused by force majeure;
7. The product's natural wear and tear, such as on housing, buttons, paint, accessories, etc.
8. Any malfunction, defect or flaw not caused by SSD.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

The following European and North American Standards have been used in the evaluation of this product:

- EN 1077 A or EN 1077 B. Class A and B helmets are for alpine skiers, snowboarders and similar groups. Class A helmets offer comparatively more protection. Class B helmets may offer greater ventilation and better hearing, but protect a smaller area of the head and give a lesser degree of protection from penetration.
- ASTM F2040 – American National Standard Specification for Helmets Used for Recreational Snow Sports

USE

Helmet for alpine skiers and snowboarders. For use in non-motorized recreational snow sports only.

WARNING

This helmet should not be used by children while climbing or doing other activities when there is a risk of strangulation/hanging if the child gets trapped with the helmet. It is important that the helmet fits your head properly and that it is correctly buckled. While no helmet can prevent all head injuries, use of a helmet, taking lessons, riding responsibly and within your abilities, and common sense, can together significantly reduce the risk of catastrophic head injury and death. However, accidents, serious injuries or death can occur even if the helmet is properly used. LIVALL makes no claim that this helmet will eliminate all possibilities of injury. This helmet is designed to absorb shock by partial destruction of the energy absorbing liner. This damage may not be visible to the user. Therefore, if subjected to a severe impact or blow, the helmet should be destroyed and replaced even if it appears undamaged. A helmet can only provide a level of protection for areas that it covers. It does not protect your neck. Do not make any attachments to this helmet, other than those recommended by the manufacturer. Doing so voids all warranties and affect the helmet's performance. The helmet may be damaged by paints, solvent, bleaches or strong detergents, sometimes invisibly.

CLEANING

Wipe only with a soft damp cloth in gentle soap or mild detergent in cold water, rinse by wiping with a soft cloth damped in cold water and dry with a soft cloth. Comfort padding can be removed and hand washed and air dried. Common substances applied to this product (solvent, cleaners, hair tonics, paint, adhesives etc.) can cause damage that may be invisible to the user and compromise the effectiveness/safety of your LIVALL helmet.

STORAGE AND TRANSPORTATION

Do not expose your helmet to impact or external force during transport. Store it in a dry place away from any source of heat like a hot radiator or sunshine through a car window. If your helmet melts it is not covered by our warranty.

MAINTENANCE AND OBSOLESCENCE

For maximum performance, your LIVALL product must be inspected prior to each use. Stop using the helmet if any components show signs of damage or are worn, cracked, and/or deformed, or if the inside foam has deteriorated. Helmets have a limited life span in use and should be replaced every three (3) years under normal use conditions, but at the latest after 5 years from date of manufacture (see product label). If you know or suspect that your helmet has been damaged or exposed to any abnormal force,

return the product to the seller for inspection or destroy and replace it. Please dispose of it in an environmentally-friendly manner. Do not make any modifications to the helmet, this includes the outer shell, the inner EPS liner or chin strap, any modifications will void all warranties and affect the helmet's performance.

FITTING INSTRUCTIONS

To attain maximum protection and comfort, choose the correct helmet size. It should sit firmly without pressing or chafing. It is important that the helmet can neither ride up your forehead nor be pushed down over your eyes.

PLEASE CONSIDER THE FOLLOWING GUIDELINES FOR A PROPER FIT OF THE HELMET.

1. Put on the helmet in a manner so that it sits straight on your head and covers your forehead, without blocking your vision. The helmet should fit comfortably; so that it holds onto your head as you move it front and back, as well as side-to-side.
2. The comfort pads inside the helmet should exert firm, even, but comfortable pressure against your head. The helmet fits well if the pads are in contact with all sides of your head around the helmets interior. A helmet that fits well also fits comfortably without being too tight.
3. When you are satisfied with the fit, tighten the chin strap so it fits snug and make sure the buckle locks securely and that the straps do not slip. If your straps aren't adjusted right, your helmet won't stay on properly. The loose ends of the strap must loop back up through the rubber „O“ ring.
4. To adjust the position of the straps, hold one end of the chin buckle in one hand and slide the adjuster up or down the strap as necessary, to create a balanced and even „Y“ shape underneath the ears. Position the buckle away from your jaw bone. It should not be possible to remove the helmet without opening the chin strap. If you can roll the helmet off in front or back, or roll it so it blocks your vision or exposes your forehead, it does not fit correctly and should be re-adjusted.



Designed and Manufactured
in Shenzhen, China

Smart4u Approved Certificate

SSD Tech Co., Ltd.
Test result Approved

Notified Body:

ITS Testing Services (UK) Ltd., Centre Court, Meridian Business Park, Leicester LE19 1WD No. 0362

Original Design Manufacturer: SSD Tech Co., Ltd.

Address: 904, R&D Building Tsinghua Hi-Tech Park, NanShan, Shenzhen, China

Postal Code: 518057

Website: www.smart4u.ai

Support & Service E-mail: riding@smart4u.ai



SS1-QA-V1.0