

CAUTION

Read the following recommendations before using the speaker. Following these you will be able to enjoy our product for many years.

- Keep it dry and don't take it to damp places to avoid the product's internal circuit being affected.
- Keep the product away from direct sunlight or hot places. High temperatures will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.
- Keep the product away from strong electromagnetic fields.
- Don't expose the product to cold areas. It may damage the internal circuit board.
- Don't try to disassemble the product as it may get damaged if you are not professional.
- Don't let it fall down onto the floor or other hard surfaces. The internal circuit might get damaged.
- Don't use intensive chemical products or detergent to clean the product.
- Don't scratch the surface with sharp things.
- Please dispose and recycle used packages, batteries, and electronic appliances properly.

The company will not incur any legal liability for the damage of personal and property caused by consumers violating the recommendations above.

Getting to know your Bluetooth Speaker

The auto-bluetooth-pairing feature of the ART-038 Bluetooth Speaker allows you to enjoy your own music theater anywhere you wish. You may also use it as a speakerphone to answer phone calls. Now, let's take a look at all parts of the speaker and its functions.


I. Keys

- ① Click Play/pause music.
- ② Click Answer/end call.
- ③ Click Volume down
- ④ Click Volume up
- ⑤ Click EQ Switch between Indoor/Outdoor mode.
- ⑥ Microphone
- ⑦ Power Button and Input / Output Jack
- ⑧ Charging Jack:
- ⑨ LED indications: Solid(continuous) red: charging (The speaker is charging the battery)
Not glowing: charged (The speaker has completely charged the battery)


Resetting the speaker : If the speaker becomes unresponsive, or behave differently than you believe it should, try resetting it. Pin the LED light with a SIM PIN . The LED will glow blue and then off, press ⑦ button. This will reset the speaker.

Connecting Your Speaker

1. Connecting your speaker to smartphones and other devices.



2. Connecting through an audio cable to the audio input.



Troubleshooting:

Q: Why does my speaker play a continuous "toot" sounds and then turn itself off ?
A: It is low on battery, please charge your speaker for 10 to 15 minutes before restarting it.

Q: Why does the LED charging status indicator turn itself off while it is charging?
A: It means the battery has been fully charged, please remove the charging cable from the speaker.

Q: Why doesn't my speaker reconnect to previously-paired source devices automatically?
A: There might be too many paired source devices saved, try to clear all pairings by resetting the speaker.

Q: Why do the music play discontinuously on the speaker?
A: Please make sure there is nothing between the speaker and the source device, and there is no other devices that may interfere the Bluetooth signal transmission(2.4GHz electric signals). You may relocate the speaker if the problem still remains.

Q: Why can't I pair the speaker with my laptop?
A: Please update your laptop's Bluetooth system and try again.

Q: Why is the voice volume low?
A: When using Bluetooth for connection, try to play your music on another audio player on the source device.
A: When the source device is connected to the speaker through an audio cable, the volume output of speaker is set to the level of connecting to an phone. However, smartphones of different brands and models may have different volume outputs, that is why it may result too low or too high volume on the speaker due to the volume output setting of the connected source device.

FCC WARNING:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference; and
(2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.
FCC ID: 2APUVART-038

Fackbook



Bluetooth hands-free speaker x1

Audio cable x 1
USB cable x 1
User manual x 1
Guarantee card x 1

GEE-D Technology (Shenzhen) Co., Ltd

Email: services@gee-d.com

Customer Support: Tel: 400-088-2228

PACKING LIST



USER
MANUAL