

SW6




Smart Switch Instruction



Since the device only supports 2.4G Wi-Fi connection, please ensure that the mobile phone and the device are connected to 2.4G Wi-Fi simultaneously.

Parameters

Model: SW6
Input: 120V~ 50/60Hz
Output: 15A Max. (Traveler+Traveler2)
Wi-Fi Frequency: 2.4GHz only
Wireless Standard: IEEE802.11 b/g/n
Operating Temp.: 0~40°C
Type 1
Pollution Degree: 2
Impulse Voltage: 2500V

Product Overview

Removable Face Plate

Light Status

- Green light flicks quickly Ready for Easy Mode connection
- Green light flicks slowly Ready for AP Mode connection
- Red light: power on or low power consumption
- The indicator light is off: power off or no output

On / Off Button (Reset Button)

Before You Install

Installation Tip

WARNING: SHOCK HAZARD

Incorrect installation may be dangerous or illegal. Multiple circuit breakers may need to be de-energized for safe installation. If you are not familiar with electrical work, please call a professional electrician.



Before You Install

Live Wire (Line Wire): A live wire is a wire carrying an electric current. If you keep your tester here, it will show indication when power is there.

Load Wire: The load wire connects your light switch to your light fixture. It is usually attached to a brass terminal on the previous switch. It is sometimes black/red. 2 load wires are required for connecting with dual dimmer switch.

Neutral Wire: A neutral wire which normally in white color allow the switch to be powered while simultaneously allowing the lighting circuit connected to your lights to be power off.

Ground Wire: Ground wire is a bare copper wire that provides a conducting path to the earth.

If the wires in your switch wall box are different from the ones listed below, we recommend consulting a qualified electrician.

Identify Wires By Color

Tip #1: An easy way to identify the wires in your wall box is by looking at the color.

Neutral	White or Gray
Ground	Green, Copper or Green with Yellow Strips
Line	Black
Load	Red or Black
Traveler	White or Black

If Line and Load Are Both Black


Tip #2: The Load wire is usually coming from the top of the box. The Line wire is usually coming from the bottom of the box.

Tip #3: Before removing the switch, test each wire with a voltage tester.

CAUTION: Risk of electric shock. Do NOT touch any wires during this process.


- After removing the face plate, turn the breaker back on.
- Very carefully, press the voltage pen against each wire.
- The pen will glow red when the wire is hot.
- The wire that causes the pen to glow red is the hot wire, also known as the Line wire.
- The wire that does not cause the pen to glow red is the Load wire.

CAUTION! Risk of electric shock. Before continuing with the next step of the installation process, make sure to turn the power breaker off.

Install the 3-way Switch Kit

Install the Switch

Step 1: Shut OFF the power at the circuit breaker for the switch you are replacing.



You may need to snip OFF wires that are not in the breaker box to make sure the switch you're installing isn't powered OFF.


IMPORTANT: USE A NON-CONTACT VOLTAGE DETECTOR OR FLIP YOUR LIGHT SWITCH A FEW TIMES TO MAKE SURE THAT THE POWER IS OFF.

Step 2: Unscrew the old switch and pull it out of the wall by using a screwdriver. Do not remove any wires.




Remove the wallplate from switch.

Remove the switch and pull it away from the wall.




Disconnect all wires from the switch.


Step 3: Install the Switch. Insert wire to the terminal, then tighten the screw.



Use a flat-head screwdriver to pry open the panel.




Connect the wires in order.




Tighten the incoming wires.

Step 4: Mount the device using the provided screws.



Use the provided screws.



Close the top cover.

If you installed the dimmer into other dimmers or switches, you'll need to install a wallplate with the correct size/number of openings to accommodate all the devices.

Step 5: Turn power on at circuit breaker.



How to Download the App

Option 1: Search for "Gosund" in the Apple App Store or Google Play.

Option 2: Scan the QR code below to enter the download page.



How to Pair with the App

- Open the APP and create your account.
- Turn on the switch and put it close to the router when pairing.
- Press and hold the ON/OFF button for 5 seconds and release it when the switch starts blinking fast, enter the network pairing mode.
- Tap "+" on the upper right corner to select "Add Manually", and then select "Switch (Wi-Fi)". Follow the App instructions to complete the operation.

Reset

Turn on the power, hold the Reset button for 5 seconds and let it go when the Switch starts to flash quickly, the reset is successful.

When the Switch is in a new network environment, you need to restore the factory settings, and then reconnect to the network.

Warnings and Precautions

- Keep it out of the reach of children and pets.
- Do not use this product in humid environments or outdoors. It's for indoor use only.
- Do not place this product near heating devices, such as microwave ovens, stoves, radiators.
- Protect the product from extreme temperatures, direct sunlight, strong jets, high humidity, moisture, flammable gases, vapors and solvents.
- Do not disassemble, modify or repair your device, and ask help from the authorized professional for device malfunction.
- Do not use the device when it is no longer working properly or visibly damaged.
- Do not store the device for extended periods in poor ambient conditions.
- Never use aggressive detergents such as rubbing alcohol or other chemical solutions because these could damage the casing or even impair the functioning of the product.

Note: The image shown in the manual is indicative only. If there is inconsistency between the image and the actual product, the actual product shall go.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



MADE IN CHINA

4.02.000.0727 V1.0

料号：4.02.000.0727 V1.0
名称：SW6白牌说明书
材质：105g哑粉纸 / 正反面4色印 / 风琴折
尺寸：75X100mm