

<div data-bbox="94 394 529 498" data-label="Section-Header"><h1>Safety Information Guide</h1></div> <div data-bbox="337 844 532 867" data-label="Text"><p>CKT.133.SIG.RORRD</p></div>	<div data-bbox="607 104 909 141" data-label="Section-Header"><h2>Safety Information</h2></div> <div data-bbox="607 168 1062 216" data-label="Text"><p>The topics in this section will introduce how to use your mobile hotspot device safely.</p></div> <div data-bbox="607 241 1042 274" data-label="Section-Header"><h3>Please read before proceeding</h3></div> <div data-bbox="607 297 1062 345" data-label="Text"><p>THE DEVICE IS NOT FULLY CHARGED WHEN YOU TAKE IT OUT OF THE BOX.</p></div> <div data-bbox="607 369 1013 434" data-label="Section-Header"><h3>Important health information and safety precautions</h3></div> <div data-bbox="607 459 1062 610" data-label="Text"><p>When using this product, the safety precautions below must be taken to avoid possible legal liabilities and damages. Retain and follow all product safety and operating instructions. Observe all warnings in the operating instructions on the product.</p></div> <div data-bbox="607 629 1062 703" data-label="Text"><p>To reduce the risk of bodily injury, electric shock, fire, and damage to the equipment, observe the following precautions.</p></div> <div data-bbox="607 728 828 761" data-label="Section-Header"><h3>Electrical safety</h3></div> <div data-bbox="607 786 1062 882" data-label="Text"><p>This product is intended for use when supplied with power from the designated battery or power supply unit. Other usages may be dangerous and will invalidate any approval given to this product.</p></div> <div data-bbox="831 927 837 946" data-label="Page-Footer"><p>1</p></div>	<div data-bbox="1133 104 1588 170" data-label="Section-Header"><h2>Safety precautions for proper grounding installation</h2></div> <div data-bbox="1133 195 1588 268" data-label="Text"><p>Warning: Connecting to an improperly grounded equipment can result in an electric shock to your device.</p></div> <div data-bbox="1133 289 1588 540" data-label="Text"><p>This product is equipped with a USB cable for connecting with desktop or notebook computers. Be sure your computer is properly grounded (earthed) before connecting this product to the computer. The power supply cord of a desktop or notebook computer has an equipment grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.</p></div> <div data-bbox="1133 566 1588 631" data-label="Section-Header"><h2>Safety precautions for power supply unit</h2></div> <div data-bbox="1133 662 1588 689" data-label="Section-Header"><h3>Use the correct external power source</h3></div> <div data-bbox="1133 707 1588 780" data-label="Text"><p>A product should be operated only from the type of power source indicated on the electrical ratings label.</p></div> <div data-bbox="1133 799 1588 873" data-label="Text"><p>If you are not sure of the type of power source required, consult your authorized service provider or local power company. For a product</p></div> <div data-bbox="1357 927 1367 946" data-label="Page-Footer"><p>2</p></div>	<p>that operates from battery power or other sources, refer to the operating instructions that are included with the product.</p> <p>This product should be operated only with the following designated power supply unit(s).</p> <p>Travel charger: Input: 100-240V, 50/60Hz, 0.5A. Output: 5V, 2A</p> <div data-bbox="1662 332 2065 359" data-label="Section-Header"><h3>Battery must be used with caution</h3></div> <div data-bbox="1662 376 2117 656" data-label="Text"><p>This product contains a Lithium Ploymer battery. There is a risk of fire and burns if the battery pack is handled improperly. Do not attempt to open or service the battery pack. Do not disassemble, crush, puncture, short circuit the external contacts or circuits, dispose of in fire or water, or expose a battery pack to temperatures higher than 140°F (60°C). The operating temperature for the device is -4°F (-20°C) to 140°F (60°C). The Charging temperature for the device is 32° F (0°C) to 113°F (45°C).</p></div> <div data-bbox="1662 676 1991 699" data-label="Text"><p>Warning: Battery is removable.</p></div> <div data-bbox="1662 724 2117 875" data-label="Text"><p>To reduce the risk of fire or burns, do not disassemble, crush, puncture, short circuit the external contacts, expose to temperature above 140°F (60°C), or dispose of in fire or water. Device and battery must be disposed or recycled of in accordance with locally applicable</p></div> <div data-bbox="1883 927 1893 946" data-label="Page-Footer"><p>3</p></div>	<p>environmental regulations or guide supplied with your product.</p> <div data-bbox="2257 170 2572 274" data-label="Image"></div> <div data-bbox="2189 314 2458 341" data-label="Section-Header"><h3>Take extra precautions</h3></div> <div data-bbox="2189 361 2643 890" data-label="List-Group"><ul style="list-style-type: none">Do not disassemble or open, crush, bend or deform, puncture, or shred.Do not short circuit a battery or allow metallic conductive objects to contact the battery terminals.Only use the USB cable provided with the device or that bear the USB-IF logo or have completed the USB-IF compliance program.Do not modify or remanufacture, attempt to insert foreign objects into the battery, immerse or expose to water or other liquids, expose to fire, explosion, or other hazards.Device usage by children should be supervised.Avoid dropping the device. If the device is dropped, especially on a hard surface, and the user suspects damage, take it to a service center for inspection.</div> <div data-bbox="2410 927 2419 946" data-label="Page-Footer"><p>4</p></div>	<ul style="list-style-type: none">Only use the battery with a charging system that has been qualified with the system per CTIA Certification Requirement for Battery System Compliance to IEEE1725. Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazards.Avoid dropping the device. If the device is dropped, especially on a hard surface, and the user suspects damage, take it to a service center for inspection.Improper battery use may result in a fire, explosion, or other hazards. If the battery leaks:<ul style="list-style-type: none">Do not allow the leaking fluid to come into contact with skin or clothing. If already in contact, flush the affected area immediately with clean water and seek medical advice.Do not allow the leaking fluid to come into contact with eyes. If already in contact, DO NOT rub; rinse with clean water immediately and seek medical advice.Take extra precautions to keep a leaking battery away from fire as there is a danger of ignition or explosion.
---	---	---	--	--	---

<p>Heed service markings</p> <p>Except as explained elsewhere in the Operating or Service documentation, do not service any product yourself. Service needed on components inside the device should be done by an authorized service technician or provider.</p> <p>Protect your device</p> <ul style="list-style-type: none">• Always treat your device and its accessories with care and keep them in a clean and dust-free environment.• Do not expose your device or its accessories to open flames or lit tobacco products.• Do not expose your device or its accessories to liquid, moisture, or high humidity.• Do not drop, throw or try to bend your device, or its accessories.• Do not use harsh chemicals, cleaning solvents, or aerosols to clean your device or its accessories.• Do not attempt to disassemble your device or its accessories. Only authorized personnel must do so.• Do not attempt to disassemble your device or its accessories. Only authorized personnel must do so. <p>12</p>	<ul style="list-style-type: none">• Do not expose your device or its accessories to extreme temperatures, minimum -4°F (-20°C) and maximum 140°F (60°C).• Please check local regulations for disposal of electronic products.• Do not carry your device in your back pocket as it can break when you sit down. <p>Damage requiring service</p> <p>Unplug the product from the electrical outlet and refer servicing to an authorized service technician or provide under the following conditions:</p> <ul style="list-style-type: none">• Liquid has been spilled into or an object has fallen into the product.• The product has been exposed to rain or water.• The product has been dropped or damaged.• There are noticeable signs of overheating.• The product does not operate normally when you follow the operating instructions. <p>Avoid hot areas</p> <p>The product should be placed away from heat sources such as radiators, heat registers, stoves, or any device producing heat.</p> <p>13</p>	<p>Avoid wet areas</p> <p>Never use the product in a wet location.</p> <p>Avoid using your device after a dramatic change in temperature</p> <p>When you move your device between environments with very different temperature and/or humidity ranges, condensation may form on or within the device. To avoid damaging the device, allow sufficient time for the moisture to evaporate before using the device.</p> <p>Notice: When taking the device from low temperature conditions into a warmer environment or from high-temperature conditions into a cooler environment, allow the device to acclimate to room temperature before turning on the power.</p> <p>Avoid pushing objects into the product</p> <p>Never push objects of any kind into cabinet slots or other openings in the product. Slots and openings are provided for ventilation. These openings must not be blocked or covered.</p> <p>Airbags</p> <p>Do not place a device in the area over an airbag or in the airbag deployment area. Store the</p> <p>14</p>	<p>device safely before driving your vehicle.</p> <p>Mounting accessories</p> <p>Do not use the product on an unstable table, cart, stand, tripod, or bracket. Any mounting of the product should follow the manufacturer's instructions and should use a mounting accessory recommended by the manufacturer.</p> <p>Avoid unstable mounting</p> <p>Do not place the product with an unstable base.</p> <p>Cleaning</p> <p>Unplug the product from the wall outlet before cleaning.</p> <p>Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning, but NEVER use water to clean the LCD screen.</p> <p>Small children</p> <p>Do not leave your device and its accessories within the reach of small children or allow them to play with it. They could hurt themselves, or others, or could accidentally damage the device. Your device contains small parts with sharp edges that may cause an injury, or which could become detached and create a choking hazard.</p> <p>15</p>	<p>Operating machinery</p> <p>Full attention must be given to operating machinery in order to reduce the risk of an accident.</p> <p>FCC Regulations</p> <p>This mobile hotspot device complies with Part 15 of the FCC Rules.</p> <p>Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>This mobile hotspot device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.</p> <p>However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to</p> <p>16</p>	<p>radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none">• Reorient or relocate the receiving antenna.• Increase the separation between the equipment and receiver.• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.• Consult the dealer or an experienced radio/TV technician for help. <p>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>17</p>
<p>RF Exposure Information (SAR)</p> <p>This mobile hotspot device meets the government's requirements for exposure to radio waves. This device is designed and manufactured not exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government. The exposure standard for wireless mobile devices employs a unit of measurement known as the Specific Absorption Rate, or SAR.</p> <p>The SAR limit set by the FCC is 1.6 W/kg. Tests for SAR are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands.</p> <p>Although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. This is because the device is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station, the lower the power output.</p> <p>While there may be differences between the SAR levels of various devices and at various positions, they all meet the government requirement.</p> <p>18</p>	<p>The FCC has granted an Equipment Authorization for this model device with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model device is on file with the FCC and can be found under the Display Grant section of www.fcc.gov/oet/ea/fccid after searching on FCC ID: 2APXW-ATTCKTHS02.</p> <p>For body-worn operation, this device has been tested and meets the FCC RF exposure guidelines for use with an accessory that contains no metal and positions the handset a minimum of 1.0 cm from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. If you do not use a body-worn accessory and are not holding the device at the ear, position the handset a minimum of 1.0 cm from your body when the device is switched on.</p> <p>19</p>				