



WHAT'S IN THE BOX

A Roku account and internet connection are required for activation.
*The projector screen is included exclusively with the LEISURE 570 WITH SCREEN package.

GET TO KNOW YOUR REMOTE CONTROL

EN - 01

SET UP YOUR PROJECTOR

1. Projector Installation

2. Powering On

EN - 02

3. Automatic Image Adjustment

The projector will automatically adjust the image for optimal clarity upon powering on.

Tip: If the initial auto-focus doesn't achieve desired results, you can manually adjust. Please visit the "TROUBLESHOOTING" section for more information.

4. Activate Your Projector

Follow on-screen setup instructions to activate your projector.

Tip: A Roku account and internet connection are required for activation.
Important: Roku never charges for activation.

Setup is done, congratulations!!

Continue using the remote to personalize your home screen, channel line-up, stream movies, and so much more.

EN - 03

PROJECTOR CONNECTION AND INPUT SOURCE

PROJECTION DISTANCE AND SIZE

* For optimal image quality, we recommend a projection size of 80". Position the projector 7.45ft (2.27m) away from the wall or screen.
* The recommended projection distance varies with different projection content. Adjust the distance between the wall/screen and the projector as needed.
* Ambient darkness will improve the clarity of the projected images and may also improve auto focus and auto keystone functions.

EN - 04

ROKU MOBILE APP

To control your projector with the Roku mobile app, you must connect your mobile device to the same wireless network as your projector.
Visit the App Store or the Google Play Store to download the Roku mobile app.

EN - 05

TROUBLESHOOTING

1. How do I improve the image clarity?
Auto Focus: You can move the projector or trigger auto focus by going to Home > Settings > Projector settings and selecting Start auto-focus.
Manual Focus: Go to Home > Settings > Projector settings > Image correction > Manual focus and follow on-screen instructions to sharpen the image until it becomes clear.

2. Could not complete auto-focus or auto-keystone?
Ensure that nothing is obstructing the lens or the camera (located next to the brand name on the front side). Try adjusting the distance between the projector and the screen. If the issue persists, power off the projector, then turn it back on before attempting again.

EN - 06

3. What should I do if the image is not rectangular?

Auto Keystone Correction: Go to Home > Settings > Projector Settings and select Start auto-keystone. The projector will automatically correct keystone distortion.
Manual Keystone Correction: Go to Home > Settings > Projector settings > Image correction > Manual keystone and follow the on-screen instructions to adjust the image using four-point correction.

4. How do I change the image size on my screen?
Consider moving the projector closer or further away from the screen to find the optimal image size for the screen. You can also adjust the image size by going to Home > Settings > Projector settings > Image correction > Zoom.

5. How to install the Remote Control Mobile App?
The free Roku app allows you to use your mobile device as a full functioning remote control with voice search & keypad.
① Download the Roku app to your phone or tablet through Google Play™ or Apple App Store™.
② Simply search for "Roku App" and choose the Roku app by Roku Inc.
③ Follow the on-screen prompts and you're on your way!

6. Cannot connect to a wireless network (Wi-Fi)?
* Select the correct wireless network name and verify the password entered (case sensitive).
* Relocate the router from objects that interfere with performance (cordless phones, baby monitors, etc.).
* Reboot the router by disconnecting the power for more than 2 minutes and reconnect.

7. Why doesn't the remote control work?
* Make sure the remote points at the IR receiver directly.
* Make sure you have installed two AAA batteries in the remote control.
* Avoid mixing new batteries with old ones in the remote control as this can result in insufficient power supply and operational issues.

8. What should I do if the projector fails to power on or automatically shuts down?
Please check and ensure that the power cable is securely plugged into the power port to prevent any accidental disconnection or loosening when moving the projector.

WARRANTY

We offer a 1-year warranty on this product. Enjoy lifetime technical support, as well as free repairs and replacements for any quality issues within the warranty period.

HDMI™
HIGH DEFINITION MULTIMEDIA INTERFACE
The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI Trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

Dolby Audio
Dolby, Dolby Audio and the double-D symbol are registered trademarks of Dolby Laboratories Licensing Corporation. Manufactured under license from Dolby Laboratories.
Google Play is a trademark of Google LLC.
App Store is a trademark of Apple Inc.

Bluetooth®
The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by [Shenzhen VanTop Technology & Innovation Co., Ltd.] is under license. Other trademarks and trade names are those of their respective owners.

EN - 07

RF Exposure Information:
The radiated output power of this device meets the limits of FCC radio frequency exposure limits. This device should be operated with a minimum separation distance of 20cm (8 inches) between the equipment and a person's body.

Canada compliance statement /Conformité réglementaire canadienne :
This device complies with Innovation, Science and Economic Development Canada license-exempt RSS standards.
Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.
Exposure to radio frequency energy:
— The radiated output power of this device meets the limits of IC radio frequency exposure limits. This device should be operated with a minimum separation distance of 20 cm (8 inches) between the equipment and a person's body.

Le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada auxquels les appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
La bande 5150-5250 MHz est réservée uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes canaux.
L'exposition à l'énergie radiofréquence:
— La puissance de sortie rayonnée de cet appareil est conforme aux limites de la IC limites d'exposition aux fréquences radio. Cet appareil doit être utilisé avec une distance minimale de séparation de 20 cm entre l'appareil et le corps d'une personne.

CAN ICES (B) / NMB (B)

EN - 09

The product complies with "RGI IEC/EN 62471-5-2015".
The product label and certification information are located at the bottom of the product.
Model: V0A11

CAUTION
Do not dispose of a battery into a fire, a hot oven, or mechanically crush or cut the battery. Do not leave a battery in an extremely high temperature environment. Avoid replacement of a battery with an incorrect type and do not mismatch battery types. Avoid subjecting the battery to extremely low air pressure. The mains plug is used as the disconnect device, the disconnect device shall remain readily operable.

The product complies with "RGI IEC 62471-5-2015".
The product label and certification information are located at the bottom of the product.

EN - 10