



# DTEN D7X 75"

Android Edition

## Product Guide


DTEN.COM SALES@DTEN.COM SUPPORT@DTEN.COM

### Packing List

1. DTEN D7X 75" Android Edition x 1
2. Wall Mount Brackets x 1
  - \* The bracket pieces are stored at the bottom of the box (beneath the foam).
3. Stylus x 1
4. Power cord x 5 (Type B,D,F,G,I)
5. USB-C to USB-C Cable x 1
6. Antenna x 2

⚠ Do not disassemble the D7X without the supervision of a DTEN technician. Improper use may be subject to voiding the warranty.


### What's Inside



### Quick Setup


#### STEP 1

Install the AV bar.



#### STEP 2


Install the antennas.



(Side view)


#### STEP 3

Plug in the power cord to the outlet.  
The display will turn on.



#### STEP 4


Follow the instructions on-screen to set up the network.  
Ethernet connection is preferred.



\* For more info about the product, please visit [dten.com](http://dten.com)

## BYOD Function with DTEN Smart Connect

Access the DTEN D7X camera system, microphone array, speakers and touchscreen as peripherals from an attached computer



## Setup and Enrollment with DTEN Orbit

1. The DTEN D7X may need to update to the latest version for the first-time startup. Please ensure the internet connection is stable during startup and update process. An ethernet connection is recommended.
2. Activate and register the DTEN D7X on DTEN Orbit for device and user management services.
3. Ensure the local area network allows the DTEN D7X to be connected. Check with your network security team for instructions. Scan the QR code below for DTEN Network Whitelist Requirements.
4. The D7X requires an active software license to connect to Zoom Rooms, Microsoft Teams or other VC providers' software. For more information, visit the service provider's website.




### Tips


1. An ethernet connection is preferred for the best meeting experience.
2. Please do not disconnect the power without first properly shutting down the D7X.
3. Do not attempt to disassemble the DTEN D7X without the instruction of a certified DTEN service provider. Unauthorized disassembly or service may void your warranty.
4. The D7X is compatible with many meeting room controllers, document cameras, audiovisual systems and other 3rd party peripherals. Consult the respective manufacturer instructions for setup and pairing information.

If you have any questions, feel free to contact us. ■ SUPPORT@DTEN.COM ☎ +1.866.936.3836


## Product Diagram



## Mounting Instructions



Mounting Hole Pattern: 800mm x 400mm



### Specifications

Model	D7X 75"
VESA	400 mm x 800 mm
Standard Screw	Ø 6 mm x 18 mm
Number of Screws	4 pcs

▲ Note: Contact a professional for assistance when wall mounting your display. We are not responsible for any damage to the product or injury to yourself. Do not power on the display when performing wall mount installation. It may cause personal injury due to electric shock.

Model: DBR1475



# DTEN D7X 75" Android Edition Safety Notice

## Important Safety Notice

- Do not use the power supply beyond the specification.
- Do not place the display on an unstable area or inclined surfaces. Otherwise, the display may fall over or this may result in fire.
- Do not put the display under direct sunlight, superheated or dusty environment; environment with flammable substances stored or used; environment with harmful or corrosive gas, bacteria, viruses and other organisms.
- Do not use damaged or improper receptacles so as to guarantee good contact between plug and socket.
- Do not attach dust or metal substances to power plug or socket.
- Do not damage power cord: do not pull power cord; do not put heavy objects on power cord; keep power cord away from heat source; do not pull power cord while taking it off.
- Do not connect too many power plugs in a socket. Otherwise, this may cause fire owing to power overloading.
- Do not use naked flame touch as heated candle flame to the display. Otherwise, this may cause an electric shock or a fire hazard.
- Do not touch plug with moisture hand. Otherwise, this may result in electric shock. Keep product away from dripping or sprinkling.
- Do not use expose the display to random especially thunderstorm. Disconnect power supply and antenna plug to prevent lightning strikes.
- Do not disassemble, repair or modify the display at your own discretion. You may be injured by electric shock or fire. All repairs must be performed by qualified service personnel.
- In case of following conditions:
  - Power failure or unstable voltage.
  - Abnormal sound or smell from the display.
  - AC power cord is damaged.
  - Display is damaged owing to falling, knocking or bumping.
  - Any liquid or foreign object dropped into the display.
- Immediately turn off the display and unplug the power plug from receptacle; contact authorized professional personnel for repairing.
- Make sure that children do not climb on the display.
- Keep the small parts out of the reach of children, to prevent accidentally swallowed.
- Do not put vase of other containers filled with fluid on the display.
- If the display is not used for a long period of time such as a travel, power off the display and unplug the power plug.
- Unplug the power plug first before cleaning the display. Use soft cloth without industrial cleaner. Avoid foreign object drop into the display.
- If it is required to adjust the position or angle of the display, unplug the power plug and move it slowly to prevent the display from dropping.
- Disconnecting device descriptor as the disconnecting device, power plug cannot be covered. It must be maintained at convenient operation status. Do not stain or scratch LCD with hard substance, or do not distort or rupture LCD.
- LCD is damaged and liquid is splashed to skin, flush skin with fresh water for 15 minutes and consult your doctor immediately.
- When you move the display by hand, hold four corners at the bottom of the display, do not apply excessive force to the panel.
- Do not display still image, track video games, computer video, electronic text, 4:3 mode display image and other images for more than 2 hours. Time limit may differ with different service conditions of the display. The warranty does not cover the permanent retention of images.
- Ways to watch display healthily: watch display under proper light; if you watch display under insufficient light for long time, it may affect your vision. When you use earphones, adjust the volume level at first protect your hearing from super high volume.



- There is a risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.
- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.
- Do not use or store inflammable substances near the display.
- Do not expose the display to dripping or splashing, and ensure that no object filled with liquid, such as vases, are placed on the display.
- In case of leakage of gas or other inflammable gases, do not plug or unplug power plug or other electric appliances. Turn off the gas supply and open the windows immediately.
- Do not place display on an unstable surface. The display may fall over, cause serious personal injury or death. May injure, particularly to children, can be a voided by taking simple precautions such as:
  - Using cabinets or stands recommended by the manufacturer of the display.
  - Only using furniture that can safely support the display.
- Ensuring the display is not overhanging at the edge of the furniture.
  - Not placing the display on the table furniture (e.g. cupboard or bookshelf) without anchoring both the furniture and the display to a suitable support.
  - Not placing the display on cloth or other materials that are located between the display and furniture.
- Warning children about the dangers of climbing on furniture to reach the display or its controls.
  - If your existing display will be retained and relocated, the above considerations should be applied. Herby, Goetek Inc. declares that his LED display / L54FCFN is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.
  - The equipment should be installed and operated with a minimum distance of 30cm between the radiator and your body.
  - Notification of the intent to market the device to EU member states may be necessary due to the restrictions in use in certain countries.
  - Operations in the 5GHz band is restricted to indoor space only.
  - If a display is not positioned in a sufficiently stable location, it can be potentially hazardous due to falling. Many injuries, particularly to children, can be avoided by taking simple precautions such as:
    - Using cabinets or stands recommended by the manufacturer of the display.
    - Only using furniture that can safely support the display.
  - Ensuring the display is not overhanging the edge of the supporting furniture.
  - Not placing the display on tall furniture (for example, bookshelves or bookcases) without anchoring both the furniture and the display to a suitable support.
  - Not standing the display on cloth or other materials placed between the display and supporting furniture.
  - Educating children about the dangers of climbing on furniture to reach the display or its controls.
- Attitude during operation: less than 5000m.
  - The lightning flash with arrowhead symbol, within an equilateral triangle is intended to alert the user to the presence of unswitched dangerous voltage within the product enclosure that may be of sufficient magnitude to constitute a risk of electric shock.
  - The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.
  - Main plug is used as the disconnect device, the disconnect device shall remain readily operable.
- Installation information: Standard: Screw: 6x6 mm x 18 mm, height: no limit.
- Comply with the notes in the operating instructions.
  - Replacement of a battery with an incorrect type that can defeat a safeguard.
  - Leaving a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
  - Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas, and a battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.
- The apparatus shall be connected to a MAINS socket outlet with a protective earthing connection.

## Toxic/Hazardous Substance/Element in the Product

Component	Toxic and Hazardous Substance or Element					
	(Pb)	(Hg)	(Cd)	(Cr <sup>VI</sup> )	(PBB)	(PBDE)
Display screen	X	○	○	○	○	○
Housing	○	○	○	○	○	○
PCBA*	X	○	○	○	○	○
Power cord and cables	X	○	○	○	○	○
Metal parts	○	○	○	○	○	○
Packing material†	○	○	○	○	○	○
Remote control	X	○	○	○	○	○
Speaker	X	○	○	○	○	○
Accessories*	○	○	○	○	○	○

This table has been prepared in accordance with SART 11364.  
 \*PCBA includes the PCB and the electronic components.  
 †Packaging materials include the carton, EPS, etc.  
 Other accessories include the User's Manual, etc.  
 ○ The content of such toxic/hazardous substances in all homogeneous materials of such component falls within the content limit specified in GB/T26572:2011.  
 X The content of such toxic/hazardous substances in one or more homogeneous materials of such component goes beyond the content limit specified in GB/T26572:2011.  
 As shown in the above table prepared based on the data provided by our material suppliers for each type of materials and verified by us, this product contains hazardous substances. The hazardous substances contained in some materials are irreplaceable at the current technological level although we're been trying to make improvements.



The environment-friendly use period of this product is 10 years (see the pollution control symbol in the right figure).

Such use period will be maintained under the normal working conditions specified in the User's Manual only.

### Indicative Description of Regulations on Recycling and Disposal of Waste Electrical and Electronic Products.

To care for and protect the earth better, please send it to a local manufacturer with nationally recognized qualification for recycling according to the national applicable laws and regulations or recycling of waste electrical and electronic products when you no longer need this product or at the end of its service life.

\*This symbol is used as the disconnect device, the disconnect device shall remain readily operable.

The apparatus shall be connected to a MAINS socket outlet with a protective earthing connection.

## Important Statement on Network Service

All contents and services obtained from the product are owned by third parties and protected by copyright, patent, trademark and/or other intellectual property laws. These contents and services are only for your personal non-commercial purposes, which shall not be used in a way not authorized by the content owner or service provider.

Under no circumstances shall our Company be liable for any direct, indirect or unexpected losses or damages arising from your or any third party's access to any contents or services or any information or third-party software through this product.

Third-party services may be subject to change, removal or discontinuation without prior notice. Our Company does not represent or warrant that some services or contents will remain accessible at any time.

Our Company will not be responsible for any service related to these contents and services, or assume any liability for customer service. For any question or service request about these contents and services, please directly contact your content or service provider.

## Disclaimer

When any of the following cases occurs, the company does not guarantee the liability of free maintenance.

- Product damages caused by violating the user guidance.
- Hardware damages caused by improper assembly.
- Product damages caused by unauthorized modification or maintenance.
- Product damages caused by using in unpermitted environment.
- Product damages caused by abnormal external force.
- Product damages caused by natural disasters or other force majeure.
- Privately tear off or damage disassembly labels.
- Unable to provide effective purchase certificate.
- The warranty will be voided if DTEN assesses any of the following cases have occurred.
- Do not disassemble the DTEN product without the supervision of a DTEN technician.

\*This symbol is used as the disconnect device, the disconnect device shall remain readily operable.

The apparatus shall be connected to a MAINS socket outlet with a protective earthing connection.

DTEN.COM SALES@DTEN.COM SUPPORT@DTEN.COM

Bluetooth BDR/EDR(ESP32) 2402-2480MHz  
 Max power:5.93  
 Bluetooth BLE(ESP32) 2402-2480MHz  
 Max power:5.78  
 Bluetooth BDR/EDR(OPS) 2402-2480MHz  
 Max power:9.47  
 Bluetooth BLE(OPS) 2402-2480MHz  
 Max power:9.83  
 2.4G WIFI 2412-2472MHz  
 Max power:19.76  
 RLAN 5.2/5.3/5.6 G WIFI 5180-5700MHz  
 Max power:21.94  
 RLAN 5.8G WiFi 5745-5825MHz  
 Max power:13.44  
 LPI 6G WiFi 5945-6425MHz  
 Max power:20.91  
 millimeter wave 24059-24239MHz  
 Max power:4.59

Hereby, DTEN Inc declares that the radio equipment type DTEN D7X 75" is in compliance with Directive 2014/53/EU

The full text of the EU declaration of conformity is available at the following internet address: [www.dten.com](http://www.dten.com)

AT	BE	BG	CZ	DK
EE	FR	DE	IS	IE
IT	EL	ES	CY	LX
LI	LT	LU	HU	MT
NL	NO	PL	PT	RO
SI	SK	TR	FI	SE
CH	UK	HR		

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.