

H5001说明书

版本:1.0

折叠尺寸:75×105(mm)


展开尺寸:375×105(mm)

材质:80G书页纸

工艺:四色印刷

折叠方式:风琴页

At a Glance



Button:

Press the button: Power on/off

Press and hold the button for 3 seconds: Get ready to connect to Wi-Fi

LED Indicator

LED Indicator	Status
Solid white	Powered on and Wi-Fi connected
No light	Powered off yet Wi-Fi connected
Solid red	No Wi-Fi connection or no internet
Flash red slowly	Preparing for Wi-Fi connection
Flash red quickly	Connecting to Wi-Fi

01

What You Get

Item	H5001101	B5001101
Smart Light Switch	1	4
Accessory Package	1	4
Wiring Label	1	4
User Manual	1	1
Service Card	1	1

Safety Instructions

Please read the Safety Instructions carefully before you start using:

- This product is for indoor use only, please do not use it outdoors.
- Please keep the product away from water, and do not spill water or other liquids on it.
- Please do not place the product near high temperatures.
- Electricity can cause personal injury and property damage if handled improperly. If you are not sure about any part of these instructions, please do not attempt to repair by yourself but seek professional assistance from a qualified electrician.

02


Installing Your Smart Light Switch

Initial operation

- 1 Please ensure the power at the circuit breaker is off before wiring.
- 2 Neutral wire is required for this product, please confirm the wall box contains a neutral wire (typically white). If there is no neutral wire in the wall box, please try other location in your house or seek a professional electrician to install the switch.
- 3 The wire colors described in this user manual are the standard colors, which might differ in some houses.
- 4 Please confirm the wire nuts are securely fastened to each wire.
- 5 Please make sure the Wi-Fi signal near the installed location is strong.
- 6 Tools you need: screwdriver, pliers and electrical tester.

Installing Steps


- 1 Turn off the original switch firstly; turn off the circuit breaker and press the switch to check if the power is off.




03

- 2 Turn off the original switch and remove the existing wall plate; turn on the power of the circuit breaker and use an electrical tester to check which wire is line wire.

- 3 Turn off the circuit breaker and use the electrical tester to test if the power is off.
- 4 Ensure the power is off; pull the original switch out and put the wiring labels on the relevant wires.



- 5 Use the slotted screwdriver to pry open the Govee smart switch plate, and then connect the switch wires to the wires in the wall box with the wire nuts.



04



Govee Home App

For FAQs and more information, please visit: www.govee.com

⑥ Mount the switch with the provided screws and snap the socket panel on it.

⑦ Turn the power back on at the circuit breaker. The switch is ready to work when the red light turns on.



Pairing Your Smart Switch with the Govee Home App

What You Need:

- A Wi-Fi router supporting the 2.4GHz and 802.11 b/g/n bands. The 5GHz band is not supported.
- A smartphone or tablet running iOS 9.3 (or above) or Android 4.3 (or above).

① Download the Govee Home app from the App Store (iOS devices) or Google Play (Android devices).

② Please ensure your phone is connected to Wi-Fi and the internet works well.

③ Open the App, tap "+" icon in the top right corner and search "H5001".

④ Tap the device icon and follow on-screen instructions to complete pairing.

Troubleshooting

Problem	Cause	Solution
Unable to turn electrical appliances on/off with the smart switch	Incorrect wiring	Make sure the switch is wired correctly
	No electricity	Check if the circuit breaker is on; make sure that the power is restored to the switch
	The electrical appliance is broken or incompatible	Replace the electrical appliance
Unable to control with the app	Network delays or is disconnected	Check the Wi-Fi network connectivity
	The Wi-Fi name or password have been modified	Re-add the device according to the instructions mentioned above
	The distance between the switch and the Wi-Fi router is too far	Move the Wi-Fi router closer to the switch
Unable to connect to Wi-Fi network	Entered the wrong Wi-Fi name or password	Please enter the correct Wi-Fi name or password
	Selected Wi-Fi network is 5GHz	Confirm your Wi-Fi is 2.4G internet, 5GHz is not supported

Specifications

Input	AC 100 - 240V 50/60Hz 10A
Output	10A Maximum Resistive Load 5A Incandescent
Wireless Frequency	Wi-Fi 2.4GHz
Wireless Standard	IEEE 802.11 b/g/n
Operating Temperature	-20°C - 50°C/-4°F - 122°F

Customer Service

⌚ Warranty: 12-Month Limited Warranty

📞 Support: Lifetime Technical Support

✉ Email: support@govee.com

🌐 Official Website: www.govee.com

Facebook: @Govee | YouTube: @Govee | Twitter: @Govee | Instagram: @Goveeofficial

Govee is a trademark of Shenzhen Intellirocks Tech Co.Ltd.
Copyright ©2020 Shenzhen Intellirocks Tech Co.Ltd. All Rights Reserved.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Govee

User Manual

Model: H5001

Smart Light Switch