

Smart Watch

User Guide

Note: Please charge the smart watch before use.

FCC ID:2AQAX-H5

Working condition requirement for mobile phone



iOS 10.0 & above



Android 4.4 & above



Bluetooth 4.0 & above

Download and pair the App

1. Download the [CoBand] from the App Store or Google play store, or scan the QR code below to download it.




Google Play



iOS

2. Device Activate & Charge

Make sure power is working normally before initial use. In case device is under low battery, connect the device to the charger. Device will automatically boot up (please connect the USB in normal DC port (5V-500mA) for charging as below. The host should be separated from the strap when charging).



3. Pair the device

Open pair device in the app, please make sure the Bluetooth is ON when pair the device. When searching and pairing device, App will search the device automatically, choose the device name and connect the device to the app.



Smart watch features

Key Definitions:


Tap: function switch

Long Press: activity & mode switch




Time Mode

Switch to the watch dial style by long press of the button.




Step mode

The smart watch automatically records the number of steps, the calories you burned and the distance you walked. The motion data is synchronized with the App.



Heart rate monitor

Get into the Heart Rate Page and automatically start measuring your heart rate.




Blood pressure monitor

Get into the blood pressure Page and automatically start measuring your blood pressure. (Only for watches with blood pressure function)



Sleeping monitor

By wearing the smart watch while sleeping, it will measure your sleep time and quality. The measured data is synchronized with the App.




Message reminder

It Can display notification content from Twitter, Facebook, WhatsApp, Instagram, Line, etc.

Latest 10 messages can be stored on the watch.




Note: if you don't need the notification, you can turn off it in the App.



Sports mode


Long press to enter the sport mode selection, then short press to switch between the five sport modes. Long press to enter the motion state, and long press again to exit.



Running




Mountaineering




Football



Cycling




Rope skipping




More interface


Long press to enter into the following functions.




Power Off




Reset



Stopwatch




Brightness



About

Notification Mode

If there is a call or message come, the device will force into call/message alert mode no matter what other mode you are in, after quit, it returns to previous mode.



Incoming call




Message



Alarm



Sedentary



Charge

FAQ

➤ The smart watch Can't pair with the phone bluetooth?

Make sure the phone's Bluetooth and GPS are on. And make sure the device is not in a low battery state.

➤ Can't connect to the App?

Restart the Bluetooth or restart your smartphone to pair with the smart watch. If you still can't connect, please reset your watch.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.