

Test Data


Frequency Stability

Condition	Mode	Frequency (MHz)	Antenna	Measured Frequency (MHz)	Deviation (ppm)	Limit (ppm)	Verdict
HVNT	a	5180	Ant1	5179.9736	-5.1	Within authorized band	Pass
LVNT	a	5180	Ant1	5179.9736	-5.1		Pass
NVHT	a	5180	Ant1	5179.9736	-5.1		Pass
NVLT	a	5180	Ant1	5179.9736	-5.1		Pass
NVNT	a	5180	Ant1	5179.9734	-5.14		Pass
HVNT	n40	5190	Ant1	5189.983	-3.28		Pass
LVNT	n40	5190	Ant1	5189.983	-3.28		Pass
NVHT	n40	5190	Ant1	5189.9832	-3.24		Pass
NVLT	n40	5190	Ant1	5189.9834	-3.2		Pass
NVNT	n40	5190	Ant1	5189.9836	-3.16		Pass


Remark: "NTNV" means Normal Temperature Normal Voltage, "NVHT" means Normal Voltage High Temperature, "NVLT" means Normal Voltage Low Temperature, "LVNT" means Low Voltage Normal Temperature, "HVNT" means High Voltage Normal Temperature.

Test Graphs


Freq. Stability HVNT a 5180MHz Ant1




Freq. Stability LVNT a 5180MHz Ant1




Freq. Stability NVHT a 5180MHz Ant1




Freq. Stability NVLT a 5180MHz Ant1




Freq. Stability NVNT a 5180MHz Ant1




Freq. Stability HVNT n40 5190MHz Ant1




Freq. Stability LVNT n40 5190MHz Ant1




Freq. Stability NVHT n40 5190MHz Ant1



Freq. Stability NVLT n40 5190MHz Ant1



Freq. Stability NVNT n40 5190MHz Ant1




Duty Cycle


Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)
NVNT	a	5180	Ant1	100	0
NVNT	a	5200	Ant1	100	0
NVNT	a	5240	Ant1	100	0
NVNT	ac20	5180	Ant1	100	0
NVNT	ac20	5200	Ant1	100	0
NVNT	ac20	5240	Ant1	100	0
NVNT	ac40	5190	Ant1	100	0
NVNT	ac40	5230	Ant1	100	0
NVNT	n20	5180	Ant1	100	0
NVNT	n20	5200	Ant1	100	0
NVNT	n20	5240	Ant1	100	0
NVNT	n40	5190	Ant1	100	0
NVNT	n40	5230	Ant1	100	0

Test Graphs


Duty Cycle NVNT a 5180MHz Ant1




Duty Cycle NVNT a 5200MHz Ant1




Duty Cycle NVNT a 5240MHz Ant1




Duty Cycle NVNT ac20 5180MHz Ant1




Duty Cycle NVNT ac20 5200MHz Ant1




Duty Cycle NVNT ac20 5240MHz Ant1




Duty Cycle NVNT ac40 5190MHz Ant1




Duty Cycle NVNT ac40 5230MHz Ant1




Duty Cycle NVNT n20 5180MHz Ant1




Duty Cycle NVNT n20 5200MHz Ant1




Duty Cycle NVNT n20 5240MHz Ant1



Duty Cycle NVNT n40 5190MHz Ant1



Duty Cycle NVNT n40 5230MHz Ant1



Maximum Conducted Output Power


Condition	Mode	Frequency (MHz)	Antenna	Conducted Power (dBm)	Duty Factor (dB)	Total Power (dBm)	Limit (dBm)	Verdict
NVNT	a	5180	Ant1	13.4	0	13.4	24	Pass
NVNT	a	5200	Ant1	13.41	0	13.41	24	Pass
NVNT	a	5240	Ant1	13.65	0	13.65	24	Pass
NVNT	ac20	5180	Ant1	13.56	0	13.56	24	Pass
NVNT	ac20	5200	Ant1	13.49	0	13.49	24	Pass
NVNT	ac20	5240	Ant1	13.76	0	13.76	24	Pass
NVNT	ac40	5190	Ant1	13.51	0	13.51	24	Pass
NVNT	ac40	5230	Ant1	13.91	0	13.91	24	Pass
NVNT	n20	5180	Ant1	13.55	0	13.55	24	Pass
NVNT	n20	5200	Ant1	13.38	0	13.38	24	Pass
NVNT	n20	5240	Ant1	13.65	0	13.65	24	Pass
NVNT	n40	5190	Ant1	13.53	0	13.53	24	Pass
NVNT	n40	5230	Ant1	13.79	0	13.79	24	Pass

Occupied Channel Bandwidth


Condition	Mode	Frequency (MHz)	Antenna	99% OBW (MHz)
NVNT	a	5180	Ant1	16.87956922
NVNT	a	5200	Ant1	16.91703292
NVNT	a	5240	Ant1	16.84459941
NVNT	ac20	5180	Ant1	17.93226296
NVNT	ac20	5200	Ant1	17.86667073
NVNT	ac20	5240	Ant1	17.8818866
NVNT	ac40	5190	Ant1	36.39777987
NVNT	ac40	5230	Ant1	36.45011054
NVNT	n20	5180	Ant1	17.86904404
NVNT	n20	5200	Ant1	17.83651068
NVNT	n20	5240	Ant1	17.89901241
NVNT	n40	5190	Ant1	36.44640342
NVNT	n40	5230	Ant1	36.3959923

Test Graphs


OBW NVNT a 5180MHz Ant1




OBW NVNT a 5200MHz Ant1




OBW NVNT a 5240MHz Ant1




OBW NVNT ac20 5180MHz Ant1




OBW NVNT ac20 5200MHz Ant1




OBW NVNT ac20 5240MHz Ant1




OBW NVNT ac40 5190MHz Ant1




OBW NVNT ac40 5230MHz Ant1




OBW NVNT n20 5180MHz Ant1




OBW NVNT n20 5200MHz Ant1




OBW NVNT n20 5240MHz Ant1



OBW NVNT n40 5190MHz Ant1



OBW NVNT n40 5230MHz Ant1




Maximum Power Spectral Density Level


Condition	Mode	Frequency (MHz)	Antenna	Max PSD (dBm)	Limit (dBm)	Verdict
NVNT	a	5180	Ant1	3.675	11	Pass
NVNT	a	5200	Ant1	3.803	11	Pass
NVNT	a	5240	Ant1	3.575	11	Pass
NVNT	ac20	5180	Ant1	3.543	11	Pass
NVNT	ac20	5200	Ant1	3.811	11	Pass
NVNT	ac20	5240	Ant1	3.421	11	Pass
NVNT	ac40	5190	Ant1	0.919	11	Pass
NVNT	ac40	5230	Ant1	0.774	11	Pass
NVNT	n20	5180	Ant1	3.468	11	Pass
NVNT	n20	5200	Ant1	3.416	11	Pass
NVNT	n20	5240	Ant1	3.619	11	Pass
NVNT	n40	5190	Ant1	0.798	11	Pass
NVNT	n40	5230	Ant1	0.574	11	Pass

Test Graphs


PSD NVNT a 5180MHz Ant1




PSD NVNT a 5200MHz Ant1




PSD NVNT a 5240MHz Ant1




PSD NVNT ac20 5180MHz Ant1




PSD NVNT ac20 5200MHz Ant1




PSD NVNT ac20 5240MHz Ant1




PSD NVNT ac40 5190MHz Ant1




PSD NVNT ac40 5230MHz Ant1




PSD NVNT n20 5180MHz Ant1




PSD NVNT n20 5200MHz Ant1



PSD NVNT n20 5240MHz Ant1



PSD NVNT n40 5190MHz Ant1



PSD NVNT n40 5230MHz Ant1

