



105g双铜纸 风琴折页 过光油

 <p>SP604 PRODUCT DESCRIPTION</p>	<p>\User Guide\</p> <p>Thank you for choosing the SP604 "Bluetooth Sport Earphone" developed by Esthetical Her! To better use this product, please read the Quick Start Guide carefully before use and properly manage it.</p> <p>Designers have set up a pair of silicone earbuds on the headset with nipple-level ultra-high water flexible silicone sleeve through repeated modification and redesign, making it more fit for ears. It won't drop even with strenuous exercise. It has also been matched by ear hooks and traditional in-ear silicon, suitable for various forms of wearing, enriching your choices. Besides, it is designed with sports-exclusive thread slipper, in a position to buckle up remaining lines and freely adjust the length. Binaural magnetic design, so no need to use when the automatic buckle in the chest, giving full play to Esthetical Her high emphasis on customer experience.</p>	<p>\Product Specifications\</p> <table border="1"> <tbody> <tr> <td>Bluetooth version</td><td>4.1</td><td>Speaker size</td><td>10mm</td></tr> <tr> <td>Bluetooth chip</td><td>CSR8645</td><td>Frequency range</td><td>20-20000Hz</td></tr> <tr> <td>Transmission range</td><td>>10m</td><td>Cable length</td><td>50±3cm</td></tr> <tr> <td>Charging time</td><td><1.5h</td><td>Sensitivity</td><td>110±3dB</td></tr> <tr> <td>Music play time /Talk time</td><td>>6h</td><td>Impedance</td><td>16Ω</td></tr> <tr> <td>Standby time</td><td>>240h</td><td>Battery Capacity</td><td>Li-Polymer Battery 3.7V/120mAh</td></tr> </tbody> </table>	Bluetooth version	4.1	Speaker size	10mm	Bluetooth chip	CSR8645	Frequency range	20-20000Hz	Transmission range	>10m	Cable length	50±3cm	Charging time	<1.5h	Sensitivity	110±3dB	Music play time /Talk time	>6h	Impedance	16Ω	Standby time	>240h	Battery Capacity	Li-Polymer Battery 3.7V/120mAh	 <p>Made in China</p>
Bluetooth version	4.1	Speaker size	10mm																								
Bluetooth chip	CSR8645	Frequency range	20-20000Hz																								
Transmission range	>10m	Cable length	50±3cm																								
Charging time	<1.5h	Sensitivity	110±3dB																								
Music play time /Talk time	>6h	Impedance	16Ω																								
Standby time	>240h	Battery Capacity	Li-Polymer Battery 3.7V/120mAh																								
<p>Caution:</p> <ul style="list-style-type: none"> Use the Bluetooth Earphone in the environment with the temperature between -10°C and 40°C. The product shall only be connected to a USB interface of version USB2.0 or higher and that the connection to a power USB is prohibited. <p></p> <p>For Battery: Risk of explosion battery is replaced by an incorrect type, dispose of used batteries according to the instructions.</p> <p></p> <p>To prevent possible hearing damage, do not listen at high volume levels for long periods.</p>	<p>EU Declaration of Conformity</p> <p>Hereby, Dongguan Esthetical Her Industrial Investment Co., Ltd declares that the radio equipment of type Bluetooth Esthetical Her SP604 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following</p> <p>FCC Radiation Exposure Statement:</p> <p>This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.</p> <p>This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.</p>	<p>NOTE:</p> <p>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p>	<ul style="list-style-type: none"> Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help <p>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:</p> <p>(1) this device may not cause harmful interference, and</p> <p>(2) this device must accept any interference received, including interference that may cause undesired operation.</p>																								
<p>\Product Information\</p> <p>■ Bluetooth Sport</p> <ol style="list-style-type: none"> 1. Ear brace 2. TPE tail rubber 3. Volume+ 4. Turn on/Turn off/Answer /End call/Reject call/Play /Pause/Previous/Next 5. Volume- 6. Charging port 7. LED 8. TPE cable 9. Microphone 	<p>\How to connect\</p> <ol style="list-style-type: none"> In off mode, long press the center button for 5 seconds to get the headphone into pairing status with an English voice prompt "Pairing". During the pairing process, the red and blue lights flash in 100MS by turns. Successfully paired: the blue light flashes twice every 4 seconds. Pairing failed: the blue light flashes once every 2 seconds. The headphones will automatically shut down if pairing fails within 5 minutes. Turn on the Bluetooth on your mobile phone, then search the Bluetooth device. Choose the Bluetooth device of "SP604" displayed on the phone and enter the pairing password "0000" to create Bluetooth connectivity with an English voice prompt "Connected". The blue light flashes twice every 4 seconds in connected status. <p>\How to use\</p> <p>Turn on: In power off mode, press and hold the middle button for 3 seconds, and there will be an English voice prompt of "tone". The red and blue LEDs will flash for 1 second.</p>	<p>Turn off: In any mode, press and hold the middle button for 3 seconds, and there will be an English voice prompt of "tone". The red and blue LEDs will flash for 1 second.</p> <p>Volume up/down: Short press the sound volume +/- 500MS, and there will be an English voice prompt of "tone" when the sound volume reaches its maximum or minimum.</p> <p>Answer/End call: Short press the center button 500MS once in ring/call status, and there will be an English voice prompt of "tone".</p> <p>Reject call: Press and hold the middle button for 1 second in the call ring status, and there will be an English voice prompt of "tone".</p> <p>Play: Short press the center button 500MS once in standby mode, the blue light flashes twice every 4 seconds.</p> <p>Pause: Short press the center button 500MS once in playing music mode.</p> <p>Previous/Next: In playing music, press and hold volume +/- for 1 second.</p> <p>Clear paired list: Long press the plus and minus buttons of sound volume for 5 seconds at the same time, the red and blue lights flash for three times simultaneously.</p> <p>Automatically entering the pairing status: Red and blue lights automatically go to the pairing state after flashing three times at the same time.</p>	<p>\How to charge\</p> <p>Using the matching Micro USB data cable and plug in the charging port to charge.</p> <p>Low battery (the remaining talk time being less than 10 minutes): there will be an English voice prompt of "tone", reminders will be sent out once per minute, the red light flashes quickly for three times per second.</p> <p>Charging: the red light stays on steadily in LED.</p> <p>Fully charged: the blue light stays on steadily in LED.</p> <p>\Important safety information\</p> <p>■ Don't remove or replace the Battery, including sensitive electronic components, including a battery, and can be damaged or cause injury if dropped, burned, punctured, crushed, disassembled, or if exposed to excessive heat or liquid. Don't use damaged batteries and electronic components.</p> <p>■ Disposal and recycling information</p> <p>Don't treat the product and battery as a household waste or into a fire. When you decide to dispose of the product and its battery, please follow the local environmental laws to handle the battery to avoid an explosion.</p>																								
<p>\Important Safety Information\</p> <p>■ Listen Responsibly</p> <p>To avoid hearing impairment, please make sure to turn down the volume of the music player before connecting the earphones. After putting the earphones into/onto the ears, turn up the volume gradually until to a comfortable listening level. Noise level is measured in decibels (db). Exposure to 85db or higher noise will lead to gradual hearing impairment. Please supervise your usage and the hearing impairment is a function of loudness against time. The louder the sound is, the shorter you can be exposed. The softer the sound is, the longer you can listen.</p>	<p>\Earplug Selection、Accessories\</p> <p>The ear hook Bullet silicone case  Sport buckle Charging line </p> <p>The suitability of the earplugs will affect the sound quality. If it is correctly worn, you can better isolate the outside interfering noise, and allow the earphones to better fit into your ears. Meanwhile, correct wearing will also make you feel more comfortable. As everyone's ear shape is different, Esthetical Her offers several differently sized earplugs. Trial and error are required to obtain the earplugs that can perfectly match your ear shape. Please find the earplugs that most suit the size and profile of your ear canal in all the earplugs attached to the earphones you have purchased. We recommend you try the smallest earplugs first, and then try the bigger earplugs, until you find the earplugs that fit and are kept in the ear in a not-easy-to-fall and comfortable manner. You can also try different types of earplugs to find the type that suits you most.</p>	<p>\Earplugs Cleaning\</p> <ol style="list-style-type: none"> It is important to keep the earplugs clean for safe and healthful use. Important notice: please remove the earplugs from the earphones first and then try cleaning the earplugs. Tightly hold the earplugs with one hand, tightly hold the earphones with the other hand, and remove the earplugs from the earphones carefully. Use a piece of wet cloth with warm water and soft soap to clean the dirt and fouling on the earplugs. Do not use powerful detergent. Rinse the earplugs and put them back to the earphones until they are fully dry. Carefully push the earplugs back to the earphones to ensure they are completely reset. <p>\Maintenance And Storage\</p> <p>■ It is important to keep the earphones clean for safe and healthful use.</p> <ol style="list-style-type: none"> When the earphones are out of use, please always store it in the clean dry environment provided. Do not store it with other articles, as it may cause pollution. Avoid contact with liquid, and avoid extreme temperature or high humidity environment. Do not stiffly pull out the earphones from the music player, but hold the terminal plug and pull it out to disconnect it. Do not dismantle the earphones in an unprofessional and nonstandard manner, to avoid partial sound of the earphones. 	<p>\Earplugs Wearing Test\</p> <p>A good way to measure if the earplugs can exactly seal your ear canal is to snap your fingers by the ear. If the earplugs can exactly seal your ear canal, you will not only do not feel "tightly plugged", but also the snaps will sound unclear and seem to be some distance away. If you can clearly hear the snaps, then it means the plugging is not enough. If the snaps are unclear and distant but the ears feel tightly plugged as if you are in a plane ready for landing, then it means the earplugs are too tightly plugged.</p> <p>\Frequently Asked Questions\</p> <p>■ Bad noise cancellation effect</p> <ol style="list-style-type: none"> Please confirm if the earplugs cannot be tightly plugged. If so, please replace with the silicone cover of a different size delivered. Please confirm if the earphones are correctly worn. <p>■ No sound or sound change</p> <ol style="list-style-type: none"> Please confirm if the current device supports this product. Please try to change a player or music playing application. 																								