


Size: 60*100mm



Getting Started

Thank you for choosing MF3, it will provide you a high-speed 4G and WiFi 6 experience.

Note
This guide briefly describes the appearance, using procedures and how to set the management parameters of MF3.

Getting To Know Your Device

2. Connect MF3 via WiFi or USB.

A. WiFi connection:

- Select the WiFi network (SSID) of this device. The default SSID is displayed on the LCD menu "SSID/Password", or you can find it on gift box and device label.
- Input the WiFi password. The default password you can see from the LCD SSID/Password menu, and also printed on the gift box and device label. You can input password strings directly, or scan 2D code with your smartphone. Below 2D code is reference only, it is unavailable.

C. Connect to WiFi via WPS.

If your device supports WPS(WiFi Protected Setup), it can be connected to MF3 without having to use the password.

Press the WPS button on this device to activate the WPS function for 2 minutes.

3. To use the storage function, please insert MicroSD card into the slot.

Note: Supports MicroSD Cards up to 32GB.

Device management

This device can be managed with signing in the WebUI(192.168.8.1), where settings can be configured to your preference.

The default password is "admin" that are printed on the device's label.

How to Charge

- Charge by power adapter.
- Charge by PC's USB port or by power bank.

Note:

- There is no power adapter included with MF3 default packaging, please purchase one separately.
- Please use a suitable power adapter(5V/1A) to charge MF3.

4. What should I do if I cannot connect MF3 via WiFi?

① Check whether SIM card is installed correctly, and check whether there's a signal in the area MF3 is being used in.(Please refer to network status).

Restore Factory Setting

If you forgot your sign-in or need to reconfigure the WiFi settings of the device, there are 2 ways you can restore its factory settings.

- Turn on MF3, open rear cover and press the Reset button once, to restore factory settings.
- Turn on MF3 and connect to it, then sign into the WebUI(192.168.8.1), and go to Admin Settings > Factory Default Settings.

5. What should I do if I forgot the WiFi's SSID or password?

Press the Reset button to restore the device's factory settings. The default SSID and password are printed on the device's label.

FAQ

1. What should I do if MF3 doesn't turn on?

Please ensure battery is not exhausted, charge MF3 and try again. Please make sure to charge MF3 at 0°C-40°C.

2. What should I do if the Internet cannot be accessed?

6. FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note
The Manufacturer is not responsible for any changes or modifications not expressly approved by the party responsible for compliance, such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The SAR limit of USA(FCC) is 1.6W/kg averaged over one gram of tissue. Device type: LTE MiFi Router with MF3 (FCC ID: 2AQRM-M3) has been tested against this SAR limit. The highest reported SAR values for body worn is 0.277/W. The Max simultaneous SAR is 0.34/W. This device was tested for typical body worn operation with the back of the handset kept 10mm from the body. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.