


# Solar String Light User Manual




If you encounter any issues while using our products, please contact our Customer Support team through your Amazon Orders page. Or you can send your inquiry to our Official Customer Support at:

Call us: (725) 255-2966  
Monday-Sunday from: 9:00AM-6:PM(PT)  
Contact via email: support@jerrite.com

①

## SOLAR PANEL GUIDELINES

- ① Turn on the switch and check that all bulbs are working correctly. If not, contact customer support.
- ② Keep the solar panel away from the bulbs or other light sources to ensure the lights activate automatically at night.
- ③ Before first use, charge the battery for 8 hours using a USB cable or place the solar panel in direct sunlight for a full day.



## PRODUCT PARAMETER

### Product Information


Material :Metal+Plastic  
Package Contents String Light / Bulb / instruction Manual / Solar Panels

Specifications	
Solar panel	2.5w/5v
Length of string	50FT
Charging time	8hours(solar) , 2 hours (usb charger 5V 1A)
Light on / off	auto
Bulb Base	E12
Bulb quantity	18Bulb+1Spare
Color temperature	2200K
Light source	LED
Mode	Lighting/Flash/Breath

⑤


## SAFETY INSTRUCTION

This manual applies to the following types of solar string lights




### ATTENTION

- ① Ensure the switch is turned on and check that all bulbs are functioning properly. If any bulbs are not working, please reach out to us for assistance.
- ② Keep the solar panel away from the bulbs or other light sources to ensure the bulbs light up automatically at night.
- ③ Before first use, charge the battery for 8 hours using a USB cable or place the solar panel in direct sunlight for a full day.
- ④ Clear snow and debris from the solar panel to maintain efficient battery charging.



⑥


## REMOTE CONTROL




## INSTALLATION STEPS

### Before Installation


Before starting the installation, ensure all parts are included and undamaged. If any part is missing or defective, do not proceed with the installation.



1. Connect the string light B with the solar panel A.




2. Testing the String Lights Press the button as shown in the diagram to verify that the string lights are functioning properly.



Press the button as shown in the figure, whether the string light can normally lit.


③

3. Install the panel by staking it into the ground or attaching it to drywall using screws and anchors.



OR

4. Charge




## CUSTOMER SERVICE

If you encounter any issues while using our products, please contact our Customer Support team through your Amazon Orders page. Or you can send your inquiry to our Official.

Call us: (725) 255-2966  
Monday-Sunday from: 9:00AM-6:PM(PT)

Contact via email: support@jerrite.com

## Q3: Short Battery Life



1. On sunny days, ensure the solar panel receives 8 hours of sunlight to provide 8-15 hours of illumination.



2. On cloudy or rainy days, use USB charging as an alternative.

## Q4: Entire String Not Illuminated

1. Verify that the solar panel has sufficient power.



Charging the solar panel using a USB cable, If the red indicator light is on, the solar panel is charging.(Please note that the power of the charging cable should preferably be 5V/1A, otherwise it may cause damage to the solar panel)



If the green indicator light is on, the battery is fully charged.Check for loose connections at the solar panel connection point and secure them if necessary.

⑦

⑧

## FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.