

- When unused, collect the receiver and keep it in the groove on the battery cover, making it easy to carry.

◆ **DPI Button**
Press the left button plus scroll wheel to adjust the resolution:
1. 800dpi (default) - LED indicator flashes once.
2. 1200dpi - LED indicator flashes twice.
3. 1600dpi - LED indicator flashes 3 times.

Caution 

- Ensure your computer is compatible with the system.
- Ensure the product receiver is connected to the USB port.
- Check if your mouse and keyboard is power on.
- Ensure your batteries are new and replace them when necessary.
- Ensure that there is no metal material between your Product and the receiver.
- If you are using USB concentrator, please directly insert the receiver into your computer.
- Avoid looking directly into the light beam of the mouse.
- Do not mix batteries of different types; do not use new batteries with old ones.
- Remove the batteries from the battery compartment if you will not be using the mouse for an extended period.

5


10. Dead batteries should be immediately removed from the battery compartment in order to avoid leakage.
11. Keep keyboard, mouse and batteries away from fire, heat or water.
12. Do not disassemble or replace parts of the keyboard and mouse.

FCC Statement:
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

Manufactured for your Military Exchanges
© 2018 Exchange
P.O. Box 660202
Dallas, TX 75266-0202
shopmyexchange.com
Printed in China

power zone CRC 1235213

2.4G WIRELESS COMBO Instruction Manual



Please read this user manual carefully before using this item.

Product Features 

Keyboard
1. Standard full-size keyboard design
2. 11 additional multimedia keys

Mouse
1. Wireless mouse with optical sensor
2. Switchable 800/1200/1600dpi resolution
3. 3-Button with scroll wheel

Combo
1. Both keyboard and mouse share same nano receiver
2. 2.4GHz wireless technology with operating range up to 26ft(8m)
3. Plug & Play



FCC ID: 2AQS3-CRC5213
Product Name: 2.4G Wireless keyboard
Model No.: CRC1235213

2.4G WIRELESS COMBO
Keyboard power rating: 3V==10mA
Mouse power rating: 3V==30mA
Interface: USB2.0
System requirements: Windows® XP/Vista/7/8/10.

Specifications are subject to change without further notice.


◆ **Package Content**
1. 2.4G wireless Combo (Keyboard and Mouse)
2. Instruction Manual
3. Nano Receiver

2

◆ **Installation**
The following figure shows the positions of the mouse's scroll wheel and buttons.

The following figure shows the function of the keyboard's multimedia keys and the back structure.



3

1. Open the battery cover of the keyboard. Put in two AAA batteries and place them in correct direction (by following the sign of positive and negative indicated inside).



2. Insert a nano receiver into spare USB port.

Mouse Installation



1. Open the battery cover on the bottom of the mouse.

2. Put in two AAA batteries and then turn on power switch in the bottom.

4