

INSTRUCTION MANUAL

Remote Control Socket (Learning Style)

Instruction

- Install the provided battery in the remote control's battery compartment, making sure the polarity of the battery is correct.
- Plug a socket into a power plug, then LED will light. And LED flashes one time per second. If LED won't flash, please press and hold the ON-OFF button on the socket for 3 seconds until the LED indicator begins to flash. The socket is ready to be connected to the remote control.
- Press and hold the ON button you have chosen for 2 seconds on the remote control. The LED on the socket will begin to flash rapidly and then stop, the socket is now connected successfully.
- Repeat the last two steps as above, choosing a different ON button on the remote control for each socket.
- To check that connection has been successful, press the relevant 'ON' and 'OFF' buttons; the LED on the socket will be switched on and off.

Operation

- Plug the device you want to remotely operate in a receiver.
- Press the relevant ON or OFF button on the remote control to operate the plug or
- Directly press ON-OFF button on the receiver to operate the plug.
- Press ALL ON or ALL OFF button on the remote control to operate all of the plug

How to Decode

- Press ON-OFF button on receiver and last for 3 seconds. After the LED flashes from quickly to once per second, decoding is successful.
- Press ALL OFF switch on remote control and last for 3 seconds. After the LED flashes from quickly to once per second, decoding is successful.

Trouble Shooting

If the socket does not respond to the remote control operation, it can be due to:

- Low battery on the remote control – Replace it.
- Distance too large between the remote control and the receiver
- The pressing time on the buttons must be at least 2 seconds

Technical data

Voltage	:	120Vac~ / 60Hz
Rating	:	15A / 1800W max.
Learning code	:	More than 1 million
Remote Frequency	:	433.92MHz
Remote Range	:	30 Meters
Code setting	:	Learning
Battery Type	:	1*3V Lithium Battery

FCC statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.