


MINI WIRELESS SPEAKER

Thank you for choosing Mini Wireless Speaker. Please read this manual carefully and keep it for future reference. If you need any assistance, please contact us with your purchase order number and details of the issue.

PRODUCT DIAGRAM



FUNCTIONS

Functions	Instructions
Power on/off	Long-press power button
Answer or end a call	Short-press power button
Redial last-called number	Double-press power button
Reject an incoming call	Long-press “M” button
Volume +	Long-press “ + ” button
Volume -	Long-press “ - ” button
Next Track	Short-press “ + ” button
Previous Track	Short-press “ - ” button
Play or Pause	Short-press power button
Mode switch(Wireless or TF)	Short-press “M” button
Disconnect Wireless	Long-press “M” button

LED INDICATOR

Status	LED Indicator
Power on	Blue flashing rapidly
Stand by	Blue flashing rapidly
Phone connected	Solid blue
Pairing	Blue flashing slowly
Charging	Red on
Fully charged	Red off


VOICE PROMPTS

Functions	Sounds
Power on	sounds like “du du”
Switch	sounds like “du”
Connected	sounds like “dong”
Low battery	sounds like “di di di di”
Power off	sounds like “dong du dong du”

FUNCTION INTRODUCTION

Wireless technology, 4.2 Smart Chip

The supported music file formats are MP3 MAV SBC



PRODUCT CARE & USE

- Keep away from liquids, extreme heat, and strong magnetic fields
- Do not use this speaker at high volume for extended periods, as this may cause permanent hearing damage or loss.
- Batteries should not be exposed to direct sunlight or near heat sources.

WARRANTY & CUSTOMER SUPPORT

For questions, support, or warranty claims, contact us at the address below that corresponds with your region. Please include your Amazon order number and product model number.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.