



# WARNING

- Do not disassemble, attempt to open or break, hit, drop, squeeze or bend the product.

  Keep the product away from fire and water.

  This product is not a toy, keep it away from children.

  Do not use the product in extremely high or low temperatures, humidity, dusty environment or at long-term exposure to sunlight.

  Do not place this product in an environment with corrosive materials. It is strictly prohibited to use chemical solutions to clean this product. Keep away from items with a magnetic strip or chip card (credit cards, bank cards), keys etc. and keep it away from other foreign magnetic equipment.

  Do not disassemble this product, to avoid causing equipment failure. Disconnect from power supply when not in use for a longer period of time.

**©**mobi<sub>®</sub>

- time.

  Do not use the product if you experience any trouble with it.

  Do not use the product if it has any damages.

# **FCC Warning**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operating interference that may cause undesired operating.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment operaries uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Regrient or relocate the receiving antenna-

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



### OVERVIEW

- Air vent clip
  Clip pusher
  Cap
  Qi2 magnetic wireless charging car mount
  LED indicator

- INSTALLATION AND USE
  1. Twist the cap clockwise to open. Insert the clip into the cap.
  2. Twist the cap counter-clockwise to lock the clip.
  3. Cannect the USB-C cable to the USB-C part and the power supply in

- Connect the USB-c. Cable to the Ostar port and the Desire Stage.

  Push down the clip pusher to mount the charger to the car air vent.

  Note: Pushing down the clip pusher is necessary also for removal.

  Place your MagSafe compatible or other magnetic device to the wireless charging car mount for charging.

  Note: To ensure charging efficiency, remove phone case before charging.

## SPECIFICATIONS

Model name	Qi2 Magnetic Wireless Charger Car				
Output	15W Max.				
Input	5.0V-3.0A, 9.0V-3.0A				
Compatibility	Apple MagSafe and other devices compatible with Qi2 standard				
Dimensions	60 x 79 x 82 mm				
Weight	123 g				
Included in the packaging	- Magnetic wireless car charger - USB-C to USB-C cable - Air vent mount - User manual				

ENGLISH

Project		Model	D481H	Edition	V1.0	
Design	YOYO	Approval		Date	2024-07-26	