

**Lytmi****LYTMI COZYCLIP D1**


CUSTOMIZED COMFORT FOR EVERY EAR

**USER MANUAL**

Model: MS7369

IC: XXXXXXXXX

FCC ID:2AR23-MS7369

**PRODUCT OVERVIEW****ADVANCED FEATURES**

**Pleasant Open-ear Listening**  
The earbuds are interchangeable, with self-adaptive left-right audiochannels, meaning you can wear either earbud on either ear

**AI Call Noise Cancellation**  
Advanced AI technology reduces background noise for clear calls in noisy environments.


**WEARING**

For a more comfortable listening experience, please adjust the wearing angle of the clip-on earbuds.

**POWERING ON & PAIRING**

Open the charging case. The earbuds will automatically power on and enter Bluetooth pairing mode when connecting for the first time. Select "Lytmi CozyClip D1" from your device's Bluetooth list.

During pairing, the LED indicator will flash white. After successful pairing, the LED white light will turn off.

**POWERING OFF**

1. Place headphones in the case and close the lid.
2. Auto-off after 3 minutes of pairing timeout.
3. Auto-off after 3 minutes of reconnect timeout.

**CHARGING**

1. Place the earbuds in the charging case and close it. Fully dry off the earbuds and the USB-C charging port before charging.
2. Connect the charging case to a power supply by using a certified USB-C charging cable.

**Low Battery Indication**


You will hear a "Dong" tone when the battery is running low.

**Charging Case**

While charging: The orange light remains on.

Fully charged: The white light stays on for 10 seconds, then turns off.

While discharging: No light indication.

**CONTROLS****RESET**

**Forced Pairing**  
Press and hold the charging case for 5 seconds to enter the forced pairing mode.

**Earbuds pairing status in the case**  
The white light will flash rapidly (for 10 seconds).

**Factory Reset**  
Press and hold the charging case for 10 seconds to perform a factory reset.

**The reset process includes:**  
1. Clearing the earbuds' volume memory.  
2. Deleting pairing records while clearing.  
3. Re-establishing TWS pairing between the left and right earbuds.

**Factory reset indicator**  
The orange light will flash slowly 3 times.

**Important note:** After resetting, the earbuds must be paired again to function properly.

**SPECIFICATIONS**

Brand	MEES
Model	MS7369
BT Version	BT 5.4
Charging Input	5V=0.6A
Battery Capacity	65mAh (Earbuds) 470mAh (Charging Case)
Charging Time	1 Hours (Earbuds) 2 Hours (Charging Case)
Waterproof Rating	IP54 (Earbuds)
Bluetooth Range	10 m / 33 ft
Hall Switch	Yes
Shipping Mode	Yes

**NOTICE**

1. Do not charge the charging case continuously for more than 12 hours.
2. Do not disassemble the headset or put the device into the fire to avoid explosion.
3. Do not place the magnetic charging cable or the magnetic charging port or the headset near metal objects.
4. Use of charging cables not approved by the manufacturer may cause fire, explosion or other hazards.
5. Use the product within the temperature range of 32°-95°F and store the product within the temperature range of 14°F-113°F. Excessively high or low temperatures may cause equipment malfunction.
6. Do not expose the headset to the sun for a long period of time, otherwise it will be easily deformed, aging and breakage.
7. This product has a built-in non-removable lithium battery, the battery is prohibited from disassembly, impact, extrusion or put into the fire, if there is a serious expansion, please do not continue to use.

**IC WARNING**

**English:**  
This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:  
1. This device may not cause interference.  
2. This device must accept any interference, including interference that may cause undesired operation of the device.

**French:**

Cet appareil contient des émetteurs/récepteurs exemptés de licence qui sont conformes aux RSS exemptés de licence d'innovation, sciences et développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:  
1. Cet appareil ne peut pas causer d'interférences.  
2. Cet appareil doit accepter toute interférence, y compris les interférences qui peuvent causer un fonctionnement indésirable de l'appareil.

**Radiation Exposure Statement**

The device has been evaluated to meet general RF exposure requirement.  
The device can be used in portable exposure condition without restriction.

L'appareil a été évalué pour répondre aux exigences générales d'exposition aux radiofréquences.  
L'appareil peut être utilisé en condition d'exposition portable sans restriction.

**FCC WARNING**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will

not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

**Warranty:** 12 Month Limited Warranty

**Support:** Lifetime Technical Support

**Email:** support@lytmi.co

**Official Website:** www.lytmi.co

**Support Phone:** (+1) 210-858-666

**YouTube:** youtube@lytmi

**Instagram:** Instagram@lytmiofficial

**Facebook:** Facebook@lytmi

**TikTok:** Tiktok@lytmi