


2. 4G wireless video doorbell

User Manual: V1.0




Before using this product, please read the instructions carefully, which is for reference only, The specific operation is subject to the physical object.

一、Appearance introduction:




1. Speaker
2. Charging port
3. Photosensitive
4. Microphone
5. Camera
6. Work indicator light
7. Door bell button






1. Display screen
2. Work indicator light
3. Reduce / turn down
4. Add / turn up
5. menu key / pair key / return
6. ok
7. Microphone
8. Answer / hang up
9. toggle the switch
10. Charging port
11. Return the key
12. TF card slot
13. Wall tier
14. horn
15. support frame

二、Conneccconnecting doorbell to indoor display:




1. Push the indoor display dial switch to "ON", long press "Menu" key, the display displays "Connect.....30", which goes into the pairing mode,
2. At the same time, long press the doorbell button, the work indicator light flashing.
3. Indoor display displays "Connect.....✓" is a successful pairing.
4. When the visitor rings the doorbell, the indoor machine rings, click "📞" to answer, then two-way intercom; then press "📞" again to hang up.

三、Introduction of keys and icon:

icon	explain	icon	explain
	Press the menu short Long press pairing		Connection signal intensity
	Answer / hang up		The voice size of the intercom
	Down / down		Door bell power
	Upturn / increase		Monitor power
	Photo file		Two-way intercom icon
	Video file		Unpaired / unconnected
	Ringtone selection		Paired in
	set up		Matching success

四、Display operation instructions:



1. Open the display switch, and the display appears normally;
2. Press the "Menu" button to enter the menu settings;



3. Press the direction keys- / ▼ and + / ▲ to select the corresponding icon.
4. Press "OK" to confirm and press "Menu" to return to the previous page.

5. If there is no operation for 30 seconds, the display screen will automatically go off. Press the key " " long for 3 seconds to wake up the display.
6. Picture: When the visitor presses the doorbell, the camera will automatically capture the visitor's image and store it in the display memory. Note: up to 40 pictures, cycle overlay, save the latest photos.
7. Video recording: This function requires inserting the TF card, ringing the doorbell, and the display will automatically open the video recording, cycle coverage, and save the latest video recording.
8. Settings:  Click to Enter Settings
 - a. Language settings: a built-in multilingual selection is available
 - b. Display brightness: adjust the display brightness
 - c. Volume setting: adjust the monitor speaker volume
 - d. Version information: display the hardware version number
 - e. Time setting: Set the monitor time
9. Time setting

YYYY	MM	DD	hh	mm
2024	06	08	08	08

Use the $-\blacktriangledown$, $+\blacktriangle$ arrow keys to adjust the value, press the  key to confirm, and press the "M" key to return.

f. Format: Clear the TF card video file

5. **matters need attention:**

- The doorbell is a low-power consumption product. When no one rings the bell, the device enters the standby mode, and the display cannot wake up the doorbell.
- Walls, Windows, metal doors, etc. will weaken the signal strength, please try to install the equipment within the strong signal range.
- Before use, pair the doorbell with the indoor display and install it in the optimal signal area.
- If the monitor is too close to the doorbell, it will produce echoes, please keep them away or reduce the volume, the noise will disappear, do not affect the normal environment use.
- The applicable working temperature of this product is $-10^{\circ}\text{C} \sim 50^{\circ}\text{C}$. Do not use it in too high temperature, too low and too wet

environment.



Tips: The display should be connected to an external power supply, which can be used for a long time. The built-in battery is for temporary backup only and cannot be used away from the external power supply for a long time.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.