




Instruction use

1. Install 4 D-cell batteries into the battery compartment located in pocket on tent. Make sure to check correct orientation of batteries before closing lid on battery compartment.
 2. Switch on the button on the speaker at the tent ceiling. The Bluetooth speaker will play one sound (ding dong) as it starts to work. The light is on and flashes quickly.
 3. Locate the Tent Speaker, using your smart cell phone.
- NOTE:** The Bluetooth speaker supports Bluetooth 5.0 and above.
4. Once they pair correctly, the blue light lights as normal and you will listen a sound similar to (ding-ding-dong-dong).
 5. While playing music using your cellphone, the blue light flashes slowly.
 6. When music is paused, but phone is still connected, the blue light will remain illuminated.
 7. To turn off - switch the button off on the speaker located on tent ceiling, the blue light will turn off.

Light signals and what they mean:

- Speaker on – light on and flashes quickly
- Once paired – lights as normal
- Playing music – light flashes slowly
- Stop playing music – lights as normal
- Speaker off – light off



FCC Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be located or operating in conjunction with any other antenna or transmitter.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.