

Safety

Safety Instructions




- Do not spill liquids on the product. Clean only with a dry cloth.
- Place the unit on a solid surface.
- Do not leave the product near any heat sources, such as radiators, heat registers, stoves or other appliances that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs and the point where they exit from the product.
- During Lightning storms, unplug the product from the power source or if unused for long periods of time. This will prevent lightning and power-line surge damage to the product.
- Do not attempt to service this product yourself. Opening or removing covers may expose you to dangerous voltages or other hazards. Please contact the manufacturer to be referred to an authorized service center near you.

- Do not overload wall outlets, extension cords, or integral power circuits as this can result in a risk of fire or electric shock.
- Never push any object through the product openings, as this can result in fire, electric shock or damage.
- Use proper power sources. When charging, plug the product into a proper power source, as described in the operating instructions or as marked on the product.

Quick start

1. Charging: Be sure the headphone is powered off, and then connect the charging cable to the USB interface of your PC/Laptop or any other USB power outlet. The LED will turn red during charging process, and it will turn off when charging is complete. Please fully charge the headphone before using it for the first time.
2. Power on and pairing: Press the power button for 3-5 seconds until the LED starts blinking blue and red alternatively and the headphone says "Power on." The headphone will then begin to pair automatically, and say "Pairing". Open Bluetooth settings on your device, find "Argon Audio POP2" on the list and then click it to pair until the headphone says "paired". You are now ready to listen to music!
3. Power off: Press the power button for about 5 seconds until the headphone says "power off."



Buttons:

1. Volume Up/Next
2. Volume Down/Previous
3. Power/Answer Call/Play/Pause
4. LED indicator
5. Microphone
6. Line in (3.5mm jack)
7. Type C charging port
8. LED indicator for charging

Specifications:

- Bluetooth version: Bluetooth 4.1+EDR CSR8645
- Frequency: 2.402-2.480GHz
- Music playing time: about 21 hours
- Standby time: about 200 hours
- Time to fully charge: about 3 Hours

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference.
 - (2) This device must accept any interference received, including interference that may cause undesired operation.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



CAUTION

Danger of explosion exists if battery is incorrectly replaced.

Replace only with the same or equivalent type of battery.

The battery shall not be exposed to excessive heat such as sunshine, fire or the like.