

The image shows the product box for the Bigger Bitty Boomers speaker and a quick start guide. The box features a large Baby Yoda illustration and the text 'Bigger Bitty Boomers' and 'BIGGER SIZE. BIGGER SOUND.' The quick start guide is a multi-panel document. Panel 1: 'In The Box' shows the speaker and a USB-C charging cable. Panel 2: 'Buttons' shows the speaker with callouts for its various buttons. Panel 3: 'Buttons' provides specific instructions for each button: Power (hold 3s to turn on/off), Play/Pause (short press), Mode (short press to toggle modes), Previous/Volume - (short press), and Next/Volume + (short press). Panel 4: 'QuickStart Guide' shows the speaker's underside with labels for its ports: USB-C Charging Port, microSD slot, and microphone. It also includes a legend for the LED indicator light and a note about auto-shutdown.

尺寸：127x127mm 双面(5折)
材质：70克
颜色：单黑

东莞市荣泉音响制造有限公司		型号:	尤达英文说明书 (美国RHT)	设计:	
技术要求	<ol style="list-style-type: none">1. 检验外观是否良好, 不可有异色、杂色、印刷模糊、漏字、重影、污迹、破损、断字等。2. 适力擦拭丝印部分, 应无掉油、模糊等不良现象。3. 丝印颜色是否符合工厂或客户要求。4. 检测材质是否符合要求。	规格:	127x127mm	审核:	
		材质:	70克打印纸, 双面, 单黑印刷	批准:	
		料号:	-	时间:	2021.08.11
		图号:	-	比例:	1/1
		版次:	V1	页次:	1/1