


LITTLE SPEAKERS...
BIG SOUND!

Specifications Item # 69901

Product Size	3.96in x 2.8in x 1.02in (100mm x 71mm x 26mm)
Bluetooth Version	5.0
Bluetooth Distance	32.8ft (10m)
Power Output Rating	1W
Charging Voltage	5V
Operating Voltage	DC3.3V ~ 4.2V
S/N	>90DB
THD	<1%
Transmit Frequency	150-16KHZ
Music Playing Time	~ 120 min
Speaker Parameter	1.18in (30mm)
Battery	3.7V / 300mAh



1. Speaker
2. Equalizer
3. Volume Control
4. Hook
5. Micro USB Port
6. Power/Pairing/Charging Indicator
7. Power/Sync Button ⊕
8. Kickstand (Handle bends backward)
9. Mini USB Charging Cable



Bluetooth® Pairing

1. Turn ON by holding the ⊕ button for 2 seconds. A voice prompt will indicate Boom Box is on and blue LED light will flash when ready for pairing.
2. Activate your phone or other device's Bluetooth function.
3. Locate and connect to the Bluetooth speaker, named "BOOMBOX".
4. When the two devices are connected, a voice prompt will indicate a successful connection and blue LED light will be solid.
5. If you are unable to play music, refresh the Bluetooth connection.
6. Adjust the volume by using the volume control dial on the front of the Boom Box.
7. When the two devices are disconnected, a voice prompt will indicate disconnection and blue LED light will flash.
8. Turn OFF by holding the ⊕ button for 4 seconds. A voice prompt will indicate Boom Box is off and blue LED light will turn off.
9. The Boom Box will turn off automatically 5 minutes after disconnected from Bluetooth.

Charging the Battery

1. When the speaker is low on battery, a voice prompt will indicate a low battery every 2 minutes until it is plugged in to charge.
2. Insert the charging cable into the Micro USB port, then connect the USB plug into a 5V/300mAh power source. A red LED light will turn on.
3. Once fully charged, the red LED light will turn off.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

We hope you enjoy your Boom Boxes™. For any inquiries or concerns, please don't hesitate to contact us.

NSI International, Inc. 30 West 22nd Street, 3rd Floor, New York, NY 10010
Customer Service Department: (888) 425-9113 or custserv@nsi-int.com
Website: www.nsi-intonline.com

© 2019 NSI International, Inc., and NSI Products (HK) Limited.
All Rights Reserved. Made in China.
Manufactured by NSI International, Inc. New York, NY 10010



© 2003-2019 by Bluetooth SIG, Inc. The Bluetooth word mark and logos are owned by Bluetooth SIG, Inc. Other third-party brands and names are the property of their respective owners.