


D3说明书

材质: 105g铜版纸（光面），单色/单面印刷，风琴折
尺寸: 75x95mm

D3

Digistar User Manual


Overview




Basic Funtion

Pairing Status	Red and blue LED twinkle alternately
Power On	Blue L ED stay on indefinitely, blue LED flash slowly when music playing
Standby Mode	Blue LED stay on indefinitely
Incoming Call Status	Blue LED flash quickly
Low Battery Status	Red LED flash quickly
Charging Status	Red LED light on in charging, red LED go out while fully charged



Turn On

Long press  for 3 seconds, the headphone will be turned on after blue LED light on for 3 seconds.

Turn Off

Long press  for 3 seconds, the headphone will be turned off after red LED light on for 3 seconds.

Volume Adjustment

Short press  and  to control volume

Specification

Profiles Supported	A2DP/AVRCP/SMP/HFP
Accept Range	8-10M
Resistance	32Ω±15%
Sensitivity	85±3dB at1KHZ
Frequency Range	20 HZ ~ 20KHZ
Charging Voltage	5V
Charging Current	500mAh
Operating Voltage	3.7V
Operating Current	8MA ~ 15MA

Accessories

1 x Headphone


1 x User manual


1 x AUX-in cable

1 x Type C charging cable


Key Note


Music Selection


Short press  for skipping to the next song


Short press  for skipping to the previous song


Play/Pause/Phone call


Music Pause: Short press  when in music playing.

Music Play: Short press  when in music paused.

Answer Calls: Short press  when a call coming in

Hang Up: Short press  when end up a call

Refuse to Answer: Long press  when a call coming in

When Bluetooth connected, double press  will re-dial the last phone number in your call record

Headphone Turn On Status

Long press on/off button for 3 seconds, the headphone will be turned on and enter into pairing mode. It will search for pair or directly connect the last successfully connected device.

Bluetooth Pairing

The headphone will enter into pairing mode automatically after turned on. Red and blue LED will twinkle alternately. Turn on the Bluetooth on your cell phone and search "D3", click to connect. The blue LED will stay on indefinitely after connected successfully, blue LED will flash slowly in music playing.

Key Note

Charging Mode

New headphones come with power, and support several times usage. When in low battery, please charge it for around 3 hours with USB charging cable. The headphones will turn off automatically when in charging. Red LED light on in charging, and red LED go out while fully charged.

Power Status

When the headphone connect with IOS device, the current power status of the headphone will be showed on the upper right corner of the device screen. And when in low battery, the headphone will voice prompt "battery low", also the red LED flash quickly.

Line-in Mode

1. Turn on status: plug in audio cable, the headphone turn off automatically, you can only listen to the music with the audio cable at the moment.

2. Turn off status: plug in audio cable, the headphone can't be turned on if you plug in audio cable, you can only listen to the music with the audio cable at the moment.

Note: If you want to listen to the songs in the Bluetooth, you need to unplug the audio cable and turn on to use.

Music Sharing Port

In the status of wireless or wired mode, insert the plug of another headphone into the left audio sharing port of the headphone, you can listen to the same music with the headphone.

Notice

Tips

1. Please charge the headphone with 5V 1A/5V 2A charger, high voltage may damage the headphone.

2. When the headphone not be used for more than 3 months, it needs to be charged before using.

3. When the headphone not be used for a long time, we suggest you to charge every 3 months to provide good protection for the battery.

Attentions

1. Please keep or use the headphone in normal temperature, avoid direct sunlight.

2. Please keep the headphone away from fire or other hot object.

3. Please keep the headphone away from damp place or submerged in liquid, keep dry.

4. Please don't try to use other method for charging other than the USB charging cable we provide.

5. Please don't disassemble, repair or modify.

6. Please pay attention to excessive clash, if any damage (like dents, deformation, corrosion, etc.), please turn to us for help by the contact information on warranty card.

7. If the headphone produces an abnormal smell, higher than normal temperature, color or shape changes abnormally, please stop to use and turn to us for help by the contact information on warranty card.

Warning

1. If the battery is replaced improperly, there is a danger of explosion. It can only be replaced with a battery of the same type or equivalent. The battery (battery pack or assembled battery) must not be exposed to the conditions such as sunlight, fire, or similar overheating environment.

2. The device should not be exposed to water droplets or water splashes. It should not be placed in objects such as vases or similar objects filled with liquids.

Note

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference.

(2) this device must accept any interference received, including interference that may cause undesired operation.