

VIVITAR®

elite ANC wireless headphones



Important Safety Precautions

When using your Elite Active Noise Canceling Wireless Headphones, basic safety precautions should always be followed including:

1. READ ALL INSTRUCTIONS BEFORE USING YOUR HEADPHONES.
2. Do not submerge your headphones in water or place on wet surfaces.
3. Do not allow children to play with your headphones without adult supervision. Keep out of reach from infants.
4. Do not expose your headphones to excessive heat, flames, or fire.
5. Always press all buttons carefully. Do not manhandle your headphones.
6. Do not use in extremely dry environments, as this can lead to static discharge during usage.
7. Do not expose your headphones to temperatures above 104°F/ 40°C. Keep out of direct sunlight.
8. Do not attempt to repair this product yourself. Contact a qualified service center if your headphones are in need of service.
9. Do not drop, throw, crush, or expose your headphones to excessive physical force.
10. Your headphones are not intended for commercial use.
11. Do not place near objects that generate a strong magnetic field.
12. Please recycle or dispose of your headphone properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your headphone for further information.



CAUTION

BATTERY WARNING:

- The device is equipped with an lithium polymer battery. The battery cannot be replaced. Do not attempt to remove the battery from the device.
- Do not dispose of in fire or expose to excessive heat.
- Do not crush, puncture, incinerate, or short circuit external contacts.
- Please recycle or dispose of the battery properly. Contact your local recycling facilities and/or the manufacturer for further information.

Introduction

Thank you for purchasing the Vivitar Elite Active Noise Cancelling Wireless Headphones, item V50032BTN. You can connect your headphones with most Bluetooth compatible devices to stream music and use Active Noise Cancelling. Please read this manual carefully before setting up and using the headphones.

Package Contents

- Vivitar Elite Active Noise Cancelling Wireless Headphones
- USB-C Charging Cable
- User's Manual with Warranty Information

Specifications

Bluetooth Version: V5.3

Bluetooth Range: Up to 33 Feet (10 Meters)

Charging Input: DC 5V, 150mA

Battery Type: 200mAh Rechargeable Lithium Battery

Charge Time: Approximately 2 Hours


Play Time:

Bluetooth Mode Only: Approximately 18 Hours**


Bluetooth & ANC Mode: 14 Hours**

***Applicable at 50% of maximum volume. Results will be lower when volume is higher*


A Closer Look




Charging



1. The USB charging cable has a USB-C plug and a standard USB plug.



2. Insert the USB charging cable's USB-C plug into the charging port on your headphones.



3. Insert the USB charging cable's standard USB plug into the USB port of a computer or suitable USB charging adapter.



Charging = Red ●
Charging Complete = Off ○

4. The LED Indicator will turn red while the headphones are charging, and turn off when charging is complete.


NOTES:

- Remove the charging cable once charging is complete.
- Overcharging could reduce the life of the battery.
- A charged battery will lose its capacity if it is not used on a regular basis.

Important: To avoid a complete discharge of the battery, charge your headphones at least once every six months.

Bluetooth Pairing

PRESS
& HOLD



1. Press and hold the Power button for three seconds to turn the headphones On.

Pairing Mode
Flashing Red & Blue LED



2. The LED Indicator will flash red and blue, indicating the headphones are in pairing mode.




3. On your phone, go into the Bluetooth page in the Settings app. Make sure bluetooth is turned On before connecting to the available device 'V50032BTN Elite ANC'.

Paired
Slowly Flashing Blue LED



4. The LED Indicator will slowly flash a blue light indicating the headphones are paired with your phone.

Music/Phone Controls




1. **Power Button:** Press to play/pause or answer/end calls. Press and hold to decline a call. Double press to activate the siri/google voice assistant.
2. **Volume + Button:** Press and go to increase the volume. Press to hold to the next track.
3. **Volume - Button:** Press and go to decrease the volume. Press to hold to the previous track.

Modes

ANC Mode:

The Active Noise Cancelling function reduces distracting background noise to provide clear sound in loud environments. You can use ANC mode when the headphone is powered on, and in combination with playing music via Bluetooth. To turn On Active Noise Cancelling mode, first, press and hold the Power button to turn the headphones On, and then press and hold the ANC button to turn ON and OFF Active Noise Cancellation.



AUX Mode:

Insert an auxiliary cable into the AUX-IN Jack to listen to music from another device. Your headphones will automatically turn On AUX mode. Note: You can play music through AUX mode when your headphone battery is low or depleted, although headphone functions and controls will be unresponsive.

Maintenance and Care

- *Before using your headphones, examine the ear cups to make sure that they are clean. Similarly, inspect any ports on your headphones to make sure that they are clear of dust and debris before charging.*
- *Use a soft cloth or paper towel to clean your headphones.*
- *When cleaning, do not allow moisture to remain inside the ear cups over long periods of time.*
- *When cleaning, never use any harsh chemicals or detergents for cleaning. Make sure your headphones are dry before charging.*
- *Always store your headphones in a cool, dry location.*
- *Do not pull or yank on the Micro USB cable while it is connected to your headphones. Connect and disconnect cables as carefully as possible.*
- *Please recycle or dispose of your headphones properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your headphones for further information.*

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Vivitar One Year Warranty

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered by Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:

Call 1-800-592-9541 or visit our website at www.vivitar.com

To receive warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepai

VIVITAR®

©2025 Sakar International
195 Carter Drive
Edison, NJ 08817
Support: 800 592 9541
www.vivitar.com