











<div><div>WYEWireless SpeakerModel: Y-SKR22</div><div></div><div>User's Manual</div></div>	<div>Button and interface description</div> <div><div><div><div>①</div><div></div></div><div>②</div><div></div></div><div><div><div>③</div><div></div></div><div>④</div><div></div></div><div><div><div>⑤</div><div></div></div><div>⑥</div><div></div></div><div><div><div>⑦</div><div></div></div></div></div> <div><div>① Short press for next song/long press for volume +</div><div>② Play/Pause</div><div>③ Short press for previous song/long press for volume -</div><div>④ ON/OFF</div><div>⑤ Charging port</div><div>⑥ Indicator light</div><div>⑦ TF card</div></div> <div>01</div>	<div>Connection method</div> <div><div>① Turn on the speaker</div><div>Turn on the speaker, the speaker will automatically enter into the wireless mode.</div><div>② Connect to mobile devices</div><div>Turn on wireless option in mobile device,select (Y-SKR22) in the mobile device,the speaker will make a sound after successful connection.</div><div>For future uses, just keep the mobile device's wireless turned on, it can automatically connect.</div></div> <div>Connect to new mobile device</div> <div><div>If the current device with the speaker is connected, you need to disconnect the current device's wireless, then use the new mobile device to connect the speaker.</div></div> <div>02</div>	
<div>Instructions for use</div> <div><div>【 + 】</div><div>Next/Volume+ Button</div><div>Short press for next song, Long press for volume +</div></div> <div><div>【 M 】</div><div>Play/Pause</div><div>Short press to answer/end phone call; when incoming call, long press to reject,</div></div> <div><div>【 - 】</div><div>Previous /Volume-</div><div>Short press for previous song, Long press for violume -</div></div> <div>03</div>	<div><div>【  】</div><div>ON/OFF</div><div>Slide to power on and off</div></div> <div><div>【  】</div><div>Indicator light</div><div>1. Charging status: the red light will be constant on; 2. Charging finished: the red light will be off.</div></div> <div>04</div>	<div>Caution</div> <div><div>Cleaning Instructions:</div><div>Please avoid using abrasive cleaners when cleaning this product.</div><div>Heat and Fire Safety:</div><div>Keep this product away from heat sources, such as cooking stoves or open flames.</div><div>Sunlight Exposure:</div><div>Avoid prolonged exposure of this product to direct sunlight.</div><div>Safe Disposal:</div><div>Never dispose of this product by incineration to prevent the risk of explosion.</div><div>Modification Warning:</div><div>Do not attempt to disassemble or modify this product, as it contains no user-serviceable components.</div><div>Weather Protection:</div><div>Do not use this product in rainy conditions.</div><div>Storage and Long-Term Care:</div><div>If you intend to store this product for an extended period, store it in a dry environment, and charge the headset at least once a month to maximize its lifespan. Keep it away from extreme temperatures and dust.</div></div> <div>05</div>	<div>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation</div> <div>This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures: --Reorient or relocate the receiving antenna. --Increase the separation between the device and receiver. --Connect the device into an outlet on a circuit different from that to which the receiver is connected. --Consult the dealer or an experienced radio/TV technician for help</div> <div>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment</div>

Size:65\*85mm折页