



Quick Start Guide

RADACAT GPS MESSENGER C2

1 Install the APP

Find and install the **RadacatCom** APP in the Google Play or Apple App store.

2 Create your account

Open the **RadacatCom** APP and register an account.



3 Activate your Radacat C2 device

- Press the power button for 3 seconds to power on your C2.
- Enable Bluetooth on your phone.
- Follow the simple in-app steps to activate your C2.
- Your C2 is now ready to use!



Note: For more features, please refer to the user manual inside the APP Help section or visit radacat.com



NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

FCC RF Exposure requirements: The highest SAR value reported under this standard during product certification for use next to the head with the minimum separation distance of 0mm is 0.640W/Kg. This transmitter must not be collocated or operating in conjunction with any other antenna or transmitter.

This product is compliance to FCC RF Exposure requirements and refers to FCC website <https://apps.fcc.gov/oetcf/eas/reports/GenericSearch.cfm> search for FCC ID: 2AS98C2

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This EUT is compliance with SAR for general population/uncontrolled exposure limits in IC RSS-102 and had been tested in accordance with the measurement methods and procedures specified in IEEE 1528 and IEC 62209. This equipment should be installed and operated with minimum distance 0 mm between the radiator and your body. This device and its antenna(s)must not be co-located or operating in conjunction with any other antenna or transmitter.

Cet appareil est conforme aux limites d'exposition DAS incontrôlée pour la population générale de la norme CNR-102 d'Industrie Canada et a été testé en conformité avec les méthodes de mesure et procédures spécifiées dans IEEE 1528 et IEC 62209. Cet appareil doit être installé et utilisé avec une distance minimale de 0 mm entre l'émetteur et votre corps. Cet appareil et sa ou ses antennes ne doivent pas être co-localisés ou fonctionner en conjonction avec tout autre antenne ou transmetteur.

Connect to your smart phone

1. Login at <http://www.radacat.ca/>, or scan QR Code below to download free Radacat App on your smart phone (available on Android and IOS).

2. Turn on Bluetooth function on your smart phone then press the "On/Off" button on Radacat device. Open the Radacat App with your smartphone and tap "Click here to scan device". Using the scan function, align your phone camera directly above the Radacat device to initiate Bluetooth pairing.

3. Once the Bluetooth connection is established, you will be able to communicate with other users with text or voice messaging, you will also be able to share your whereabouts by using the "location sharing" function. Tap open "Manual" under "Me" on Radacat App to learn more.



Get to know your device



Operating Your Device

On/Off Button	Function	Action
Hold down	Power off	Hold the button for 3 seconds
Single press	Power on	Press button once
Double press	Display device's ID Code. (Tap open "My Device" under "Me" on App to check device number. The last 3 digits should match with your device ID Code).	Press button twice quickly

Screen Instructions:



Charging Status



Device initiating



Not connected to smartphone



Sending/
Receiving message




Device ID Code



Successful connection

Battery Status



Product Specifications

Product Specifications:	Relative Parameter
Screen:	OLED Display
Bluetooth:	Bluetooth 5.0
Battery:	1350mAh
Sensor:	Temperature Sensor
Charging Port:	Micro USB
Transmitted Power:	less than 1 W
Battery Type:	Lithium-ion
Weight:	55g
Dimension:	109*39*14mm
Operating Temperature:	-20 – 60°C
Operating Range:	up to 6km in open area

Caution

Location hazard:

- To ensure safety of the user, do not use the device near hospitals, pacemakers, on the plane, or any other areas /times that restrict the use of electronic devices.
- Do not use near gas stations or any other inflammable environments (areas that might contain inflammable gas, gun powder, or other flammable substances).
- Do not use in areas/times that restrict wireless electronic products.

- Device Malfunctions (signs of smoke, smell, heat etc) Immediate stop using the product if you discover signs of smoke, unusual smell, heat or other unusual state from the device. Turn off the areas that might contain flammable substance to avoid fire disasters.

- Please contact Radacat customer service to receive instructions.

Other cautions:

- Do not disassemble or customize the device.
- Do not immerse device in water, or burn the device.
- Do not strike, throw or put pressure on the device.
- Always use the designated charger to charge the device, check the voltage and amperage on your charger.

- Do not leave device in direct sunlight or damp environments for long periods of time.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.