

# User Manual

## 1. Set Up and Get Started

### Activate

Please charge the watch to activate it before first use.


**Follow these steps:**

- Connect the magnetic charger to the USB power adaptor.
- Align the charger correctly with the watch's charging contact.
- Charge the watch for a few minutes until the screen turns on.

**Note:**

- Make sure the USB charging plug is at the same side as the watch crown.
- It is recommended to use a standard USB power source with an output of 5V-1A or above.
- Before charging, ensure to clean the watch's charging contacts to remove any sweat or moisture.
- After fully charging, please disconnect the watch from the charger.

**GTX2**



2ASAU-GTX2  
Shenzhen Starmax Technology Co.,Ltd  
31F, Building 2, Huasheng Longyue Tower,  
Jinglong Community, Longhua Street,  
Longhua District, Shenzhen, China.

1


## 2. App Download and Connection

### (1) App Download




For Android phones: Go to Google Play, search and install "Runmeifit".  
For iPhone: Go to App Store, search and install "Runmeifit".

**Quick installation:** Scan the QR code on the right to download "Runmeifit".



### 3. Operation Instruction

#### (1) Watch Crown/Button Function



Press

- Wake up the screen.
- Enter the menu from the watch face.
- Go back to the watch face.
- Press and hold to shut down or restart.

#### Scroll

- Toggle between screens.
- Navigate through menus.

#### Shortcut Button

- Press to start Workout quickly.
- Press and hold to activate SOS.

2

### (2) Connection

#### 1. Remove the Band

- Loosen the spring bar from the groove.
- Push and hold the spring bar as shown.
- Install the band to the watch and release the spring bar.
- \* Or tap "≡" to scan the QR code on your watch to connect.

**Note:**

- You must use "Runmeifit" app to pair the watch.
- DO NOT pair the watch in the phone's Bluetooth settings.
- Allow all pop-up permissions requested by the "Runmeifit" app.


#### 2. Change the Watch Face

Press and hold the screen for 1 second to change the watch face.




#### 3. Record Workouts

Access the Workout app and select a specific workout to start your workout recording.



#### 4. Control Center

Swipe up on the watch face screen to access the Control Center. Enable features like Silent Mode, Sleep Mode, Always-on Display, and adjust brightness and volume swiftly.



#### 5. Help and Guide

For outdoor workouts, wait in an open area until the GPS connects. The blinking icon "GPS" shows it's acquiring a location fix and will stop blinking upon success.

#### 6. Product Manual

Go to Device > How to Use the "Runmeifit" app. Enter "help.runmeifit.com" in the browser. Scan the QR code to get the product manual.



3

4

5

6

## 3. Change the Band

### (2) Common Functions

#### 1. Remove the Band

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### 2. Install the Band

Do not replace the internal battery by yourself to avoid potential safety risks.


Notification Center

Swipe down on the watch face screen for 1 second to change the watch face.



#### 3. Record Workouts

Press and hold the screen for 1 second to change the watch face.



#### 4. Control Center

Access the Workout app and select a specific workout to start your workout recording.




#### 5. Help and Guide

For outdoor workouts, wait in an open area until the GPS connects. The blinking icon "GPS" shows it's acquiring a location fix and will stop blinking upon success.


#### 6. Product Manual

Go to Device > How to Use the "Runmeifit" app. Enter "help.runmeifit.com" in the browser. Scan the QR code to get the product manual.



#### 7. How To Wear the Watch

For more accurate measurement data, please attach the watch's sensor side to your skin. Leave at least a finger width between the watch and the wrist.



7