




How to connect Catchmon with phone for first time

Insert two AAA batteries and DualCatchmon will automatically start. 1P and 2P will flash green several times and enter work mode before connection.



2. Go to Pokemon Go and click "Main Menu"

3. Click "Settings" in upper right corner


4. Go to bottom and click "Pokémon Go Plus". Two available devices (Catchmon 1P and 2P) are shown below.

1P 2P A green light will flash in Catchmon before it connects with phone.

5. Press Catchmon 1P or 2P. A light will appear at the center of available device in phone. Click on desired device on phone to start connecting with Catchmon.



6. After successful connection, available devices on the app will light up like the graph.



If Catchmon had successfully connected with phone before and signal is lost, LED will be blue and flashing. To reconnect, simply click Go Plus icon at top right in phone app map. (Purple light flashing if connection successful)

To connect with new phones, first delete old Catchmon connection. Methods are indicated as follows.

Catchmon tips

1. Catchmon's built-in random delay capture time.
2. If bag is full and cannot collect items from Pokestop, first deactivate "Nearby Pokestop" notification in Go Plus.
3. If out of red Pokéballs and temporarily cannot capture, first deactivate "Nearby Pokémon" notification in Go Plus. Alternate and make it easier to collect, capture, and acquire stardust.

NOTIFICATIONS

Nearby Pokemon

Nearby Pokestop

Function and light description

Press Catchmon button to switch between the different light functions.

Press once and go from blue light > green light > purple light in order. Switch to the desired light option, then set up based on the instructions below.

1P 2P Blue light: to disconnect

Catchmon with a new phone, first delete previous connection memory. After pressing and blue light comes on, long press for 3s to disconnect.

When disconnecting, blue and yellow flashing light will appear in Catchmon.

Disconnection successful: green light flashes
Disconnection unsuccessful: red light flashes

1P 2P Green light: notification sound switch

Green light: sound on

Green breathing light: sound off

In green light display, press for 3s to switch off notification sound setting.

Turned on: green light flashes

Turned off: red light flashes

1P 2P Purple light: vibration switch

Purple light: vibration on

Purple breathing light: vibration off

In purple light display, press for 3s again to switch off vibration setting.

Turned on: purple light flashes

Turned off: red light flashes

※Long press both buttons for 3s. Red light will flash several times and both sound and vibration functions will be turned off.

Light, sound and vibration description

connection status display

light	status	sound	vibration
● Red flashes	Low battery	NA	NA
● Green	Awaiting bluetooth connection	1P-beep~ twice ; 2P-beep beep~ twice	single vibration twice
● Blue	Bluetooth connected / Signal disconnected	1P-beep~ twice ; 2P-beep beep~ twice	single vibration twice
● Purple	Signal connection successful	NA	NA
● Red	Phone unable to connect to Internet	beep~ triple	single vibration triple

※Within 3min, connection status (sound & vibration) is prompted every 10s; between 3-10 min, every 30s; longer than 10min, no prompted.

Game status display

light	status	sound	vibration
● Blue	Within range of a PokeStop	NA	NA
● Green	A Pokemon is nearby	NA	NA
● Yellow	A Pokemon is nearby (haven't caught)	NA	NA
○ White	Catching Pokemon	NA	NA
● Red	Pokemon runs away.	NA	NA
● Multicolor	Successfully catching a Pokemon or visiting a PokeStop	NA	NA
○ White	Item storage is full	Beep~ triple	Single vibration triple
● Red	Out of Pokeball	Beep beep beep~ triple	Tri-vibration triple
● Red	Out of range of the PokeStop	Beep beep~ triple	Dual vibration triple

Additional Instructions

Catchmon consumes very little power and has power-saving and sleep mode features.

Pokemon app will automatically disconnect from Catchmon every hour. If not reconnected after 10min, Catchmon will go into sleep mode. Player can press Go Plus connection icon in app anytime and automatically call up Catchmon to reconnect. When changing batteries, DualCatchmon will retain all settings in memory so reset is not necessary.

If unable to connect with Catchmon, please try the following:

1. Disconnect Pokemon Go Plus Bluetooth device in phone.
2. Go to game settings and disconnect Pokemon Go Plus.
3. Turn off game and restart.
4. Restart Catchmon and Pokemon Go App connection.

P.S. Pokemon Go App, Android and iOS system upgrades may cause Catchmon to not connect. Multiple Catchmons in one place will also cause Bluetooth interference in phone and cause disconnection.

FCC Caution

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions : (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Non-modification Statement :

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Radiation Exposure Statement :

The device has been evaluated to meet general RF exposure requirement, The device can be used in portable exposure condition without restriction.

Compatible with iPhone 6 or higher devices with iOS Ver. 11 or higher installed.

Compatible with Android devices with 2 GB RAM or more. Bluetooth Smart (Bluetooth Ver. 4.0 or higher) capability and Android Ver. 7.0 or higher installed.

Copyright © Sperry Corporation All Rights Reserved.

Dual Catchmon is the trademark of Sperry Corporation. Pokemon / PokemonGo / Pokemon Go Plus are the trademarks of Nintendo. The other trademark names are the used marks, trademarks or registered trademarks of the corresponding companies. This Product is not sponsored, endorsed, or approved by Nintendo, ThePokemon Company Or Niantic.

Made in Taiwan

SPERRY CORPORATION

369 , Fu-Shin North Road , Taipei Taiwan

www.dualcatchmon.com

Brand: MEGACOM

Model No: DC-1218

Power Rating: DC 3V, AAA batteries*2

