

# Bluetooth operation manual

**Bluetooth solutions:** CB6925 Bluetooth 5.0

**Frequency :** 2.4 GHZ to 2.48 GHZ

**Signal to noise ratio:** 90dB

**audio distortion:** <0.05%@500mVrms

**Bluetooth brands:** JL

**Transmission distance:** 8 M

**Loudspeaker :** 4 Ω 3W size Φ 45mm

**Battery:** 3.7V 1200 mAh

**Service time:** The battery will last for three hours after fully charged.

## How to connect:

1. Turn on the switch of the products then you will hear a “ding-dong” prompt tone which means the bluetooth is ready.
2. Enable the terminal bluetooth settings and search for bluetooth JR001 and link in. It has been connected successfully once you hear the prompt tone of “dong” .(The first time of connection may be a little slow , please be patient to connect)
3. Please use the USB cable to recharge the battery when you hear the low battery warning. The audio effect and lamp will be weaker if the battery is low.

## FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to

the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/ TV technician for help

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment . This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.