## User manual

- Shutdown status: Press Bluetooth key for five seconds→Blue light will be on and flash quickly for four times Press the key for another two seconds→Pairing status: red and blue lights flash altematel y→
  - 1) Search →Blue light flashes quick for four times →Stand-by
  - 2) Less than one minute after searching→Stand-by
- 2. Stand-by mode: blue light flashes quickly for three times every three seconds.

Press Bluetooth key for three 3 seconds  $\rightarrow$  Bluetooth will shut down and red light flashes quickly for four times.

- 3. Call-in mode:
  - 1) Press bluetooth key for one times  $\rightarrow$  Answer a call.
  - 2) Press bluetooth key for three seconds→Reject a call.
- 4. Talk mode: blue light flash quickly for four times every three seconds during talking .
  - 1) Press bluetooth key for one time to end talking.
- 5. Sniff and Hold mode : blue light flashes for one time every three seconds .
- 6. Shutdown: press Bluetooth key for three seconds, a red light flashes for four time→Shut down
- 7. Low battery; red light flashes quickly for three times, a "Beep" can be heard on the headphone.
- 8. In operating mode, short press Volume+ or Volume-repeatedly to adjust the volume.
- 9. When charging, red light always remains on.
- 10. Introduction to pairing

Pairing is a process to connect Bluetooth equipments each other. It will create a permanent and safe link between your equipments and provide them with quick service from Bluetooth without using any password.

Every eyewear, s default pairing password is 0000 and stored in ist internal memory. Generally, password 0000 is needed to enter by users to pair your eyewear with Bluetooth mobie or other equipments, which depends on specific setting of equipments to be paired. Please refer to specific operation section in equipment, s user manual for Bluetooth password.

After your eyewear has been paired with mobile successfully, you can use headphone to dial or answer

a call.

Paired equipments will keep paired status even if any one of the following cases occurs:

- . Any one of the equipments shuts down.
- . Any one of the equipments is disconnected or stopped.
- . Any one or two of the equipments restarts.

Made in china

## **FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - -Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.