



Qi WIRELESS CHARGING LED TASK LAMP

DPCI# 074-14-6489 / 074-14-6490

BEFORE YOU BEGIN


Please read this guide before using the device to ensure safe and proper use.

CHARGING BASE

1. Qi wireless charging pad: Place a qi-enabled mobile device in the center of the charging surface, for example, iPhone x/ 8/ 8 Plus up , or Samsung Galaxy S7/ S8/ note 8 up
2. 5V USB Port, non-wireless charging port: For mobile device not supporting qi wireless charging, simply to charge the mobile device via USB cord (not included)

CLEANING

Do not use polishes or cleaners, wipe it clean with soft cloth. Wipe clean with a soft, dry cloth or static duster.



Caution

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference, and
- 2) This device must accept any interference received, including interference that may cause undesired operation.

Importer: Target Corporation

Address: Minneapolis, MN 55403

Telephone: 1-800-440-0680

Caution statement:

Warning: Modifications not approved by the party responsible for compliance could void user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.