


Remote control instructions

1. The key functions of the panel are shown in the figure



2. Function description: long press the power start button for 3 seconds, and

the blue wireless indicator will turn on. Power off automatically after 2 minutes without any operation. Press the OUT button. The blue indicator flashes winch outgoing (nylon rope/steel cable). Press IN button blue indicator light flashes winch incoming (nylon rope/steel cable).

3. Distance: ≤ 40 feet. In case of different degrees of interference in the actual use environment, the distance of remote control will also change correspondingly (the distance will be shortened).

4. Transmitter voltage: DC2-3.6v, Receiver voltage: DC9-15v

FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following

two conditions: (1) This device may not cause harmful interference, and (2) this device

must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital

device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the

user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible

for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator&your body.