

User's Manual MZ-628

- Read all instructions and save them for future reference.
- Do not place it near a heat source. Avoid using radiators.

- Read all instructions and save them for future reference.
- Do not place it near a heat source. Avoid using radiators, stoves, and other equipment that can generate heat. Avoid long-term exposure to sunlight and high temperatures.
- Please note that when Bluetooth is disconnected for 10 minutes, the speaker will enter sleep mode and shut down. To restart the speaker, press the power switch/mode button.

- Speaker
- USB data cable
- User manual

- Speaker
 - USB data cable
 - User manual
- ### Product Parameters
- Working hours: 4-6hours
 - SNR: >95dB
 - Wireless distance: ≤10m
 - Frequency: 200Hz-20KHz
 - Bluetooth version: V5.4
 - Battery capacity: 600mAh
 - Charging time: 1-2hours
 - Working voltage: DC 3.7V
 - Rated power: 5W
 - Waterproof grade: IP67
 - Product size: 47*75*34mm
 - Net weight: 64g




The diagram consists of two line drawings of a handheld electronic device. The left drawing shows the front view, and the right drawing shows the back view. Numbered callouts are as follows:

- 1:** Points to the speaker grille on the front face.
- 2:** Points to the top of the screen on the front face.
- 3:** Points to the bottom of the screen on the front face.
- 4:** Points to the bottom bezel of the front face.
- 5:** Points to the bottom edge of the device, showing the hinge mechanism.
- 6:** Points to the back cover of the device.

- ① **Volume up key:** single press for volume up, long press for the next song.
- ② **Power switchmode:** Press and hold for 3 seconds to turn off. When there is an incoming call, short press to answer the call, long press to reject the call. During a call, short press to end the call. In Bluetooth mode, short press play/pause. Double click to forcibly disconnect the Bluetooth connection and enter pairing mode.
- ③ **Volume down key:** single press for volume down, long press for the previous song.
- ④ **Power indicator:** DC 5V
- ⑤ **Working indicator light (blue/red light)**
- ⑥ **Clip**
- ⑦ **Mic (Environmental Noise Cancellation)**

Step 1

- Press and hold the power button "O" for 3 seconds

- Step 1**
- Press and hold the power button  for 3 seconds to activate Bluetooth mode. The blue light will flash, indicating the speaker is ready to pair with your mobile device.
- 
- Step 2**
- Turn on the Bluetooth function on your phone or other Bluetooth device, and then search for a speaker named **MZ-628**. Connect to the speaker.
- Step 3**
- After successful pairing, there will be a prompt sound and the blue indicator light will remain on.
- Step 4**
- Play music on your phone.
- When playing music, the blue indicator light will remain on.
- 
- Indicator Light

The speaker auto-reconnects to the last device upon powering on, and turns off after 10 minutes if not connected.

- If the device's Bluetooth feature is enabled, the speaker will automatically connect to the last paired device upon powering on.
- Double-click the Power button "O" to disconnect the current device, and double-click again to reconnect current device.

- When the battery is low, the speaker will sound a warning sound and need to be charged.
- The red indicator light remains on during charging, but goes off when fully charged.
- It is recommended to charge products with lithium batteries every three months when not in use.

- Press and hold the power button "O" for 3 seconds to shut down and hear the battery percentage.

- **Answering Calls:** When the speaker is connected to your phone, you can answer incoming calls by briefly pressing the play/pause button "O".
- **Rejecting Calls:** To reject an incoming call while the speaker is connected to your phone, press and hold the play/pause button "O".
- **Ending Calls:** During a call, press the play/pause button "O" briefly to hang up.

Cycling Hiking Walk Walkies

Work Housework Jogging Construction

Need further help, you can contact us by
A. Service Email: inwa_support@innosystemtech.com
B. Or Scan the QR code for quick contact.

1. Go to Your Orders.
2. Find your order.
3. Select "Problem with order."
4. Choose your topic, then select your problem.

Madrid, 28947 Spain
GST_EU_20230424000022 successservice2@hotmail.com
We simply act as EU representative for cross-border sellers, and are not
manufacturers/importers/distributors for the product, nor involved in the
manufacture/import/sale of the product.
Therefore, we are not responsible for any after-sales services related to
the product. In case of any product quality or infringement issues, the
manufacturer/importer/seller shall be solely held responsible.

Operation is subject to the following two conditions: (1) this device must not cause harmful interference, and (2) this

The device complies with part 15 of the FCC Rules. Changes to this device may cause harmful interference, and (2) this device must accept any interference received, including interference caused by radio transmitting devices. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's warranty.

NOTE: This equipment has been tested and found to comply with the requirements for Class B digital devices, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the antenna of the receiving system on or off, the user is advised to take one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable mode without restrictions.