

▶ || long press this button for 3 second, the speaker will power on and blue light will flash.
Open your bluetooth device then search "My BT Speaker". Click it and wait for connecting
After connected, the blue led light will flash quickly, and you will hear a prompt sound
Long press this button 3 seconds, the speaker will power off.

◀▶/-, short press this button : previous song
Long press this button: volume down
+◀▶/. short press this button: next song
Long press this button : volume down

When charging, the red light will be on, after fully charged, red light is off.

The speaker only have AUX IN function and bluetooth mode

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance

could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.