

Function Operation

THE function switch select to "BT.USB.SD.MMC" position for USB or SD/MMC card or bluetooth mode:

- 1.The SD/MMC card and USB not plug in the machine for bluetooth play mode.
- 2.The SD/MMC card and USB plug in the machine for SD/MMC card and USB play mode.

INTERNAL BLUETOOTH FUNCTION OPERATION

Turn on the radio bluetooth and the bluetooth of cellphone or other mobile devices with bluetooth function start to search a bluetooth named "BLUETOOTH" and pair with it. After successful pairing, it will beep. Now cellphone or other mobile device can play the mp3 through bluetooth on radio.

You can select play and pause the mp3 by pressing NEXT/PREV/PLAY buttons on radio or cellphone or other mobile devices. If you want to stop using bluetooth function just need to turn off the bluetooth in cellphone or other mobile devices. If want to use it again, only need to open the bluetooth in cellphone or other mobile devices again and pair with "bluetooth" automatically

POWER SUPPLY

Battery operation:

Open the battery compartment and insert 4 pcs UM-1 penlight batteries.

PLAY BACK

1. Set the Function switch to TAPE.
2. Press the stop button to stop all functioning buttons.
3. Insert the cassette with the full reel to the left.
4. Tape slot toward the front.
5. Depress the play button and your player will begin to play back.
6. Adjust volume Knob to give the best listening level.
7. To stop the playback, depress the stop button.

RECORDING

You can recording from the radio/live/SD/MMC/USB/Bluetooth. Once the cassette tape is ready and inserted you will need to setup the boombox. Make sure the function switch is set on the function which you want to recording (radio/live/SD/MMC/USB/Bluetooth). When you are ready press "PLAY" and "REC" together. When you are ready to stop recording press "STOP/EJ." to stop the cassette tape or leave it to run out of tape on the current side.

RADIO

1. Set the Function selector to Radio "AM/SW or FM" position
2. Tune in the desired station by turning the Tuning Control.
3. Volume is adjusted with Volume control to desired sound level.

SPECIFICATIONS

Power Supply: AC: 120V/60Hz
UM-1x4PCS BATTERIES

Frequency: AM: 530-1600KHz SW: 8.00-16.0MHz
FM: 87-108MHz

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction