



Product Video demo



WARNING

There are small parts inside possibly causing a choking hazard, so the product isn't suitable for children 3 years old and below. When the product is being used, an adult must be on the scene for guardianship and guidance. These instructions have important information and thus shouldn't be discarded randomly. They should be kept properly for future inquiry.


Not suitable for children under 8 years old
Please read through this manual before use.



ITEM NO: 338-1

DRIFT CLIMBING KING

INSTRUCTION MANUAL



DRIFTING



PROGRAM



SOUND



RISE AND
FALL



DANCE



LIGHT

<SAFETY PRECAUTIONS>

- It is a radio control model, not a toy!
- In order to enjoy running the car, you need to finish assembly before operation. Do routine maintenance work after operation. Replacement parts and option parts are available separately.
- Improper usage with Alkaline cells or rechargeable batteries may damage the electronics for the car or the radio.

<IN ORDER TO OPERATE THE CAR SAFELY, BE SURE THAT YOU HAVE OBSERVED THE FOLLOWING POINTS:>




WARNING!

Please follow the points as below in order to prevent accident from happening to the car and people.



- Be sure to read thoroughly the manual before you begin. Fresh user should seek advice from people having rich experience in order to assemble the model correctly.



- Never reverse connection / disassemble the battery. This may lead to damage and leakage.



- As the product contains small and sharp parts, assemble and store this product only in places out of the reach of children.



- Do not operate the model on public roads, in crowded places and near infant as it may cause accidents.



WARNING!

Please follow the following steps to operate, in order to prevent hurt to your body or damage of material property.




- Cutters, nippers and screwdrivers need careful handling.




- Painting must be done only in a well-ventilated area.

- When the model is not in use, always turn off the receiver and transmitter. Further more, disconnect the batteries and remove them from the model and the transmitter. This may be dangerous such as overheat and leakage.



- Do not expose this model to high temperature, humidity or direct sunlight.



OPERATING YOUR MODEL SAFELY

WARNING!

Do NOT operate the model in the following places and situations.
(Non-observance may lead to accident!)

- Operate your model in spacious areas ONLY with few people around! Do not operate it:


1. On road!
2. In places where children and many people gather!
3. In residential districts and parks!
4. Indoors and in limited space! Non-observance may result in personal injury and property damage!

- The car must stop immediately and check for the reasons when it is operating abnormal.

As long as the problem is not cleared, do NOT operate it! This may lead to further trouble and unforeseen accidents!

- Always check the radio batteries!

With weak dry batteries, transmission and reception of the radio would fall off. You may lose control of your model in such condition. This may also cause serious accidents!!



- Keep in mind that people around you may also operate a radio control model!

NEVER share the same frequency with somebody else at the same time! Otherwise, Radio signals will be mixed up and you will lose control to your model. This may lead to accidents.




WARNING!


In order to avoid accidents and personal injury, be sure that you have observe the following points:

- The safety of battery :

1. Exhaust battery should be safety dispose!
2. Non rechargeable batteries are not to be recharged, there is danger of explosion!
3. Do not throw the of battery into a fire! There is danger of explosion!
4. Do not swallow battery!
5. Store only in cool, dry and dark places and should be keep out of the children!
6. When the battery leaks the liquid and let it into you eyes, please right away rinse them and consult an ophthalmologist.



PROHIBITED



- Do NOT put fingers or any objects inside rotating and moving parts!
- Right after use, do NOT touch the motor! Danger of burning yourself!

WARNING!

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ☐ Reorient or relocate the receiving antenna.
- ☐ Increase the separation between the equipment and receiver.
- ☐ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ☐ Consult the dealer or an experienced radio/TV technician for help.
- ☐ This device complies with Part 15 of the FCC Rules.


Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.


Contens

Included the following parts


- Body (To the actual product)




- Transmitter




- 7.4V 1400 mAh Large power Li-Po battery



- Instruction manual



- USB Charge line




- Screwdriver




About the Radio

1. Frequency description: Turn the power switch of the remote control car to the "ON" position, the power will be switched on, and the operation indicator light of the remote controller will be off, which means that the frequency pairing is completed.
2. Accept the machine plug schematic.




Model battery's charging and assembly

1. Take out the rechargeable battery from the product as shown in the diagram.




2. Put the USB connector into the USB interface of the computer, after which the red charge lamp of the USB will be on; then, insert the lithium battery plug into the USB charging plug, after which the green charge indicator light of the USB will flicker; after full charging is completed within about 180 minutes, the green charge indicator light will be on long, which indicates charging complete and the product will work in 5 minutes. Overcharging may damage the batteries, cause burnings or catch a fire.



Notice:



When the product is idle, please push its power switch to “OFF”, and take out the batteries in case the service life of the rechargeable batteries is affected.

3. Load the battery pack in the battery case by corresponding to the correct electrodes, and cover up the battery cover.



R/C Car assembly diagram


-  19
- LS0001 2.3x6mm
Screw
-  2
- LS0002 2.6x8mm
Screw



 11
 LS0001 2.3x6mm
 Screw

 2
 LS0004 4x6x7mm
 Screw


3



A3

 4
 LS0001 2.3x6mm
 Screw

4




A4

LS0002 2.6x8mm Screw 4

GZ0001 2.5x25mm Pin 2

5

A5




LS0001 2.3x6mm Screw 3


GZ0002 1.5x15mm Pin 4

6


A6



-  2
 LS0001 2.3x6mm
 Screw
-  4
 LS0002 2.6x8mm
 Screw



-  4
 LS0002 2.6x8mm
 Screw




LS0003 15x5x9mm Step screw 2

9

A9

A8




LS0003 15x5x9mm Step screw 2

10

A9


LS0003

LS0003




A10

11




A11



x4

LS0003 15x5x9mm
Step screw 2

12




A12

A10

A11

LS0003 15x5x9mm
Step screw 2

13



A12

LS0003

S15150504


A13

A11

 4
 LS0005 3.5x6.5mm
 Crew cut screw

14


B1



 6
 LS0002 2.6x8mm
 Screw
 6
 LS0005 3.5x6.5mm
 Crew cut screw


15

B2



-  2
LS0002 2.6x8mm
Screw
-  2
LS0003 15x5x9mm
Step screw


16



C1

-  2
LS0002 2.6x8mm
Screw
-  2
LS0003 15x5x9mm
Step screw


17



C2

-  4
LS0001 2.3x6mm
Screw
-  2
LS0006 15x7mm
螺丝 Screw


18



C3


-  4
 LS0001 2.3x6mm
 Screw
-  2
 LS0006 15x7mm
 螺丝 Screw

19



-  1
 LS0001 2.3x6mm
 Screw

20



21

