

157克双铜，折页，骑马钉, size:260x100mm



THE INSTRUCTIONS

01



SCAN TO DOWNLOAD

WOPET INTELLIGENT DOG CAMERA USER MANUAL

Android



Apple



02

## DOWNLOAD THE APP & CREATE ACCOUNT



Register Account




Add Device



Select the Device in Use

TO ADD DEVICE(S), LOGIN BY ENTERING YOUR USERNAME & PASSWORD



CONNECTING THE DEVICE TO WIFI



TO PAIR THE DEVICE, SCAN THE QR CODE DISPLAYED IN THE APP USING THE DEVICE CAMERA






IF YOU DO NOT HEAR BEEP SOUND, PLEASE CLICK ON THE BUTTON TO USE WLAN  
TO CONNECT TO THE DEVICE INSTEAD.

05




Wi-Fi



PLEASE USE THE DEVICE WITHIN 10 METERS UNOBSTRUCTED RADIUS OF  
THE WIFI ROUTER TO ENSURE THE BEST USER EXPERIENCE

06



### WOPET at a Glance



"SET" Button: Quick press to pop a treat, Long press for 5 seconds to restore factory settings



#### Status Light Indicator

D01 Status Light	ALARM (RED LIGHT)	LINK (GREEN LIGHT)	Status
Off	Flashing slowly	Ready for configuration	
Off	Flashing rapidly	Connecting to network	
Off	Solid green	Connected to network	
Flashing slowly	Off	Snack box empty or blocked	

#### Technical Specifications

Product Name: Wopet Intelligent Dog Camera

Product Dimensions: Length 147mm \* Width 147mm \* 254mm

Product Weight: 972.5g

Product Material: ABS

Camera: 123° Wide Angle HD Camera with Night Vision

WiFi Frequency: 2.4G

APP Installation Requirements: Android 5.0 or above / iOS 7.0 or above

Adapter Parameters:

Input: 110-240V, 50/60HZ, 0.4A

Output: 5.0V, 1000mA

### **Importance Notice**

- 1.Do not unplug the adapter directly by pulling out the cable.
- 2.Please do not insert foreign object into the product.
- 3.Please do not modify or repair the product on your own.
- 4.A person who is without the capacity of civil conduct and relevant knowledge (including kids) must operate, clean and perform maintenance on the device under the supervision and guidance of a guardian.
- 5.Please stop using the device if the adapter or cable is not functionally properly.
- 6.This product should only be used indoor.
- 7.Only insert dry pet food into the snack box, which the recommended dimension is under 18x10mm.
- 8.This electronic device is not waterproof and recommended to be used in dry environment.
- 9.This device is not suitable for any other purposes other than monitoring and accompanying pet(s).
- 10.Should this product malfunction, give off a peculiar smell, or smoking, please stop using it and contact customer support.
- 11.Please watch out for the surrounding at the time of snack feeding to avoid hitting human or pet's eyes by accident.
- 12.Please clean up the surrounding pet food to avoid consumption by children.

### **FAQ**

- 1.What are the reasons that the snack popper is not responding despite the request had been sent via the mobile app?  
Ans: There are a few possibilities:  
(A)There are signs of the food has been dispensed but it is indicated that the snack box is empty – check if the opening of the dispenser is broken or blocked.  
(B)The network might be disconnected or delayed due to slow connection – Try again for a few more times and check if the connection is normal.
- 2.Why is the device popping the snacks multiple times when the “toss a treat” request is sent via either the mobile app or manual feeding button?  
Ans: When the device failed to detect available snack to dispense, it will attempt to toss a treat for a maximum of 4 times. Should it failed to do so after 4 times, a message on empty snack box will pop out on the mobile app and the status light indicator will turn into red – Please check if the snack box is empty.
- 3.What causes the frequent disconnection on video call?  
Ans: Please ensure that the device is connected to the A/C. Besides that, please check that the mobile device and the device are connected to the network.

4.What should I do if I could not login to my account?

Ans: Firstly, please ensure that the network connection is working. Secondly, check if anyone is logged in using your account. Please try uninstalling the app and attempt to login again. If you are using an Android phone, try doing the following:

Go to phone > Settings > Manage Application > WOPET App > Clear all data > Clear Cache And try logging in again.

5.How do I switch my WOPET account to pair with the device?

Ans: Unfortunately, the app does not support switching of account. If the switching of account is necessary, please register a new account using a new email address and unpair the device by long pressing the SET button to restore factory settings. Lastly, repair the device to your new account.

Note: You cannot pair the device to a new account without unpairing it from the existing WOPET account.

6.Should you have any other question, please visit the following website for enquiry:

<http://www.wopet.com>  
support@wopetshop.com

**FCC Rules**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or an experienced radio/TV technician for help. Shielded interface cable must be used with the equipment in order to comply with the limits for a digital device pursuant to Subpart B of Part 15 of FCC Rules. Specifications and designs are subject to change without any notice or obligation on the part of the manufacturer.

**Warning:**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

**RF Exposure Statement**

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter