



## TTNM OPEN EAR WRLS AUDIO

 **Bluetooth® 5.3**  
**USER GUIDE**

### INTRODUCTION

Listen to music without interruptions with your new Probuds Plus+ Bone Conducting Headphones. With up to 8 hours of playback time, these headphones let you enjoy your favorite tracks all day long. Featuring Bluetooth 5.3 compatibility and cutting-edge bone conduction technology, they transmit sound directly to your inner ear through your cheekbones, freeing your ears so you can hear everything around you. Lightweight and designed for all-day wear, the Probuds Plus+ Bone Conducting Headphones are the perfect everyday audio companions.

### WHAT'S INCLUDED

- Bone Conduction Headphones
- USB-C Charging Cable
- User Guide

### FEATURES

- Easy-to-use controls.
- USB rechargeable via the included charging cable.
- Up to 8 hours of playback time.
- Wireless HD stereo sound wherever you go.
- IPX6 waterproof rating.

## PRODUCT DIAGRAM



## SPECIFICATIONS

- Input: 5V/1A
- Battery: 150mAh
- Charging Time: Up to 5 hours
- Play Time: Up to 8 hours (at 70% volume)
- Bluetooth Version: 5.3
- Waterproof Rating: IPX5
- Dimensions: 5.3 x 3.9 x 1.6 in.
- Weight: 1 oz.

## BLUETOOTH CONNECTION

Enable your device's Bluetooth function from its Settings menu. Search and select "#69744 Headphones" from the Bluetooth devices list to pair the headphones to your device. Once paired, you will hear a voice prompt indicating that your headphones are connected. Your Probuds Plus+ headphones are now ready to use!

## CHARGING INSTRUCTIONS

Plug one end of the USB-C charging cable into the headphones, and the other end into a USB power source. The LED indicator light will glow red while charging, and will turn blue once the headphones are fully charged.

## VOICE ASSISTANT

Press and hold the "+" for 2 seconds. You will hear a beep and your device's voice assistant/Siri will activate. This function may not work with all devices.

## SAFETY INSTRUCTIONS

- Avoid dropping or applying excessive force to the controls.
- Do not attempt to repair, disassemble, or modify the product.
- Only store the product in a dry place, away from extreme temperatures, humidity, and dust.
- Do not listen to music at a high volume for extended periods of time.
- Do not use this unit for anything other than its intended use.
- Keep the unit away from heat sources, direct sunlight, humidity, water, or any other liquid.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Keep this unit out of the reach of children. This product is not a toy.

## BASIC CONTROLS

- Power ON: Press and hold the MFB button for 3 seconds.
- Power OFF: Press and hold the MFB button for 3 seconds.
- Play/Pause: Press the MFB button.
- Increase Volume: Press the "+" button.
- Decrease Volume: Press the "-" button.
- Next Track: Press the "+" button twice.
- Previous Track: Press the "-" button twice.
- Activate Voice Assistant: Press and hold the "+" button for 2 seconds.
- Answer a Call: Press the MFB button during an incoming call.
- End a Call: Press and hold the MFB button for 2 seconds during a call.
- Reject a Call: Press and hold the MFB button for 2 seconds during an incoming call.

## FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 2ATF5-69744