

## Multimedia wireless microphones

### Product features :

1. SMD electronic parts, SMT technology, excellent quality, distance 30 to 50 meters
2. The shock return frequency circuit, frequency stability and frequency not road, dead center
3. Effectively prevent computer, DVD, digital power amplifier
4. Has the noise suppression, switch eliminate circuit noise impact
5. High sensitivity, make you relaxed, the original sound reproduction
6. The USB power supply without batteries

### Use of places:

Use family card, karaoke ok network, video chat, market promotion, outdoor rally speech, classroom, military training, the tour guide, exhibition and other places of small propaganda.

### Technical parameters:

The range of frequency: 214.2 MHz  
Frequency stability: 50 PPM (5-10 du °C - 35 °C)  
Frequency response: 60 hz - 13 KHZ


### The receiver:

Within the receive mode: the poor  
Receiving sensitivity: better than 12 is a 40 db (S/N =)  
Modulation mode: FM  
Working temperature: - 10 du °C to 35 °C  
distance: 30-50 meters

### The emitter :

Transmission power: - 4 dbm  
Working current: ≤100 mA

### Receiver operating instructions



#### Model A operation instruction :

Insert the USB input computer USB socket or with USB socket megaphone, careless of the indicator, and then insert the cut in 3.5 into the MIC jack, when receiving the wireless signal power will more bright lights, microphone can be normal use


#### Model B operation instruction :

After the 5th battery into receiving box, will switch to the ON the documentation, LED lights dim, then cut in 6.3 insert the MIC jack, when receiving the wireless signal power will more bright lights, the receiver can be normal use.

### The instructions on the emitter :

#### Method of use:

Remove the battery cover, according to the marked polarity equipped with batteries, turning the battery cover; Push the switch to the second leg "ON" position, indicating lights, said the battery is normal, can work normally; When the light is dim, it means electricity shortage or put wrong polarity, the battery must be replaced.



#### Matters needing attention:

1. Using a microphone, noise, sound, staccato occur, is inadequate battery, battery should be replaced.
2. After use, the switch to "OFF" position 3. When not in use for a long time, please take out the battery, acidification, prevent battery leakage, lead to damaged parts

### **Federal Communications Commission (FCC) Statement**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by Xian Chishine Optoelectronics Technology Co.,Ltd may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.