

FCC ID: 2ATIITD-YK2019

## OPERATION

### REMOTE CONTROL

NOTE: Maximum range remote control: 15m

NOTE: Remove the protective strip from the remote control's battery compartment before operation.

### Switching on/off

- To switch on the product, press the ON button.
- To switch off the product, press the OFF button.

### Timer

- To activate the timer mode, press the TIMER button. The green timer indicator lights up on the controller of lighting-chain.

NOTE: Once the timer mode is activated, the product operates in 8 hours on - 16 hours off cycles.

- To deactivate the timer mode, press the TIMER button again. The green timer indicator goes off.


### Lighting modes

- Press the 1 to 8 button to choose the desired mode. Choose from:

- 1 Steady on
- 2 in waves
- 3 sequential
- 4 slo-glo
- 5 chasing/flash
- 6 slow fade
- 7 twinkle/flash
- 8 combination

## BATTERY REPLACEMENT

1. Press the tab on the side of the battery compartment's tray.
2. Slide out the tray.
3. Take out the exhausted battery and dispose of properly.
4. Place a new CR2025 battery on the tray. Ensure the correct polarity.
5. Slide the tray back into the battery compartment.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

MADE IN CHINA