

\*\* description of MENU Mode setting

"Long push" means 2 second delay, "Push" means 1 second delay

1. Menu mode in : Long push by M key(long beep sound generated)  
then 7-Segment "MENU" displayed.
2. Menu mode Out : : Long push by M key (long beep sound generated)  
then 7-Segment Idle displayed.
3. Server IP setting procedure of Gateway
  - 3-1. Menu mode in
  - 3-2 M3 key push (ex: IP setting of 192.168.0.49)
  - 3-3. confirm 192 in 7-Segment, next each M3, M4 key pushed, then (M3/↑) increment or  
(M4/↓) decrement

At this time,  Key push, then current digit setted,  key pushed and manu input canceled.

Set 168.0.49 as same procedure

#### 4. IP setting procedure of Gateway

- 4-1. Menu mode in
- 4-2 Push M3 key (ex: case of IP: 192.168.0.47, Netmask : 255.255.255.0, Gateway : 192.168.0.1 )
- 4-3. confirm 192 in 7-Segment, next each M3, M4 key pushed, then (M3/↑) increment or  
(M4/↓) decrement

At this time,  Key push, then current digit setted,  key pushed and manu input canceled.

Set 168.0.49 as same procedure

4-4. Netmask : 255.255.255.0 and Gateway : 192.168.0.1 setted as same procedure

## FCC Statement

15.19: This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

5.21: Note: The grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

15.105(b): Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## Disclaimers

The manufacturer, importer, and distributor shall not be liable for damages including accidental and personal injury due to the improper use or operation of this product.

The information in this user manual was written based on current product specifications.

The manufacturer, iriver Limited, is adding new complementary features and will continue to apply new technologies in the future.

Product specifications may be changed without prior notice.

iriver is not responsible for data loss due to product use.

## Exposure statement

The transmitter must not be co-located or operated in conjunction with any other antenna or transmitter. This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and any part of your body.