

Dear Valued Customer:

Thank you for your purchase of our Wireless Dog Fence.
It is our great honor to serve you.

In order to provide you the best service, please kindly send your *Amazon Order Number* to our service team

Aweec-service@outlook.com

we will provide you **2-year** product warranty for free.

Please do not hesitate to contact our Customer Service Team by e-mail (**Aweec-service@outlook.com**) if any questions about the product. We will take your concerns seriously and promise to resolve them to your complete satisfaction.

Sincerely Yours,
Team Aweec

User Manual

2 in 1 Wireless Dog Fence & Training Collar



Aweec 2 in 1 Wireless Training System combines the functions of wireless dog fence and training collar. Our system adopts the most advanced technology with 2.4G signal source which is much more accurate and stable than any other old versions in the market.

Please read the instructions carefully before use.

- Please use this device in an open area, the transmitter should be placed 3 feet above ground at least to avoid barriers which will disturb radio signal.
- Not recommended for aggressive dogs. DO NOT use this device if your dog is behaving aggressively.
- If you are not sure that if this device is right for your dog, please talk to your veterinarian or a certified dog trainer.
- No more than 12 hours per day to wear the receiver collar.
- If a rash or sore is found, stop using the collar until the skin is healed.
- Always keep dog's neck clean.
- Keep this device away from children.
- This device is intended to use for dogs only.



1 Transmitter	2 Waterproof Receiver
1.1 LED Screen	3 Adjustable Reflective TPU Collar
1.2 Mode Button	4 USB Cable
1.3 Sound	5 Metal Probes * 4pcs (2 small one for short hair dog, 2 big one for long hair dog)
1.4 Vibration	6 Test Tool
1.5 Shock	7 Safe Silicone Cap * 4pcs (Cover the metal probes when didn't training dog)
1.6 ON/OFF	
1.7 Increase	
1.8 Reduce	

Quick Start

- Press ON/OFF button to start the device.
- Press **Mode** button to switch between **Wireless Fence Mode** and **Remote Training Mode**.
- There are 10 different setting ranges: 1-10 levels, the range is 10ft - 990ft from the transmitter to the receiver
- When the screen shows 1/2/3/..../10 means the device is on **Wireless Fence Mode**, red light on the receiver collar.
- When the screen shows 001/002/003 means the device is on **Remote Training Mode**, the figure shows the number of dogs (up to 3 dogs), green light on the receiver collar.

Working Principle

Wireless Dog Fence Mode

Under Wireless Fence Mode, you will see 1/2/3/..../10 on the LED screen (red light flashing every 5 seconds on the receiver collar), which means the setting range is between 10ft to 990ft, you can adjust the setting range by pressing “+” and “-” button.

- There is no need to pair between transmitter and receiver. This mode can work directly after power is on. One transmitter can control up to 5 dogs at the same time.
- Set a range on the transmitter, then put the receiver collar on dog's neck.
- When dogs are within the setting range, the receiver collar will not work.
- When dogs are out of the setting range, the receiver collar will work as below:
 1. **Sound for 3 seconds, vibration for 3 seconds, sound & vibration for 3 seconds, shock for 3 seconds, sound & shock for 3 second**
 2. After 2 cycles of working mode, it will emit di-di sound until the dog returns to the setting range, then the receiver collar will stop working.
- The receiver collar will automatically switch to standby mode if it does not work for more than 5 minutes.

Remote Dog Training Mode

Under Remote Training Mode, you will see 001/002/003 on the LED screen (green light flashing every 5 seconds on the receiver collar), which means the number of dogs, it can control 3 dogs at the same time and train each dog by selecting the number.

- One transmitter can control up to 3 dogs at the same time. When using this mode, pair the receiver and the transmitter first (see the instructions).
- The figure shows on the screen indicates that 001 for the first dog, 002 for the second dog, and 003 for the third dog. It can be selected by pressing “+” & “-” button on the transmitter.
- There are 3 functions to train dogs: Vibration, Shock, Sound.
- Vibration and Shock have 3 levels to adjust. Smaller number shows on the transmitter means shorter time, bigger number means longer time. You can adjust the level by pressing “+” and “-” button.

How to Pair Transmitter with Receiver

1. Turn on both transmitter and receiver.
2. Under **Remote Training Mode**, choose dog number on the transmitter (001/002/003)
3. Long press **Power** button on the receiver for 2 seconds, red & green light flashing.
4. At this time, press any key of sound/vibration/shock on the transmitter.
5. When the receiver collar got the signal and work as sound/vibration/shock, green light flashing every 5 seconds, it means paired successfully!

Test in advance:

1. Shock Testing:

Please test the shock function by using the testing tool (included in the package), put it on the 2 metal probes, when electric shock works, the light in the tool will on. If it's not working, please kindly contact us by e-mail: Aweec-service@outlook.com

2. Receiver Collar Testing:

Set a range on the transmitter first, then walk with the receiver collar until it starts with warning sound and red-light flashing, this indicates the receiver collar is within the warning zone. If you move away further, the receiver collar will start working mode:

Warning sound for 3 seconds, vibration for 3 seconds, sound & vibration for 3 seconds, shock for 3 seconds, sound & shock for 3 second

To avoid over-stimulation to the dog, electric shock will not work anymore after 2 cycles of working mode, but the warning sound will last until the dog go back to the setting range.

3. Put On Receiver Collar:

After finishing the above tests, screw the metal probes on the back of receiver (2 small one for short hair dog, 2 big one for long hair dog). Put the receiver collar on dog's neck, then adjust the belt neither too loose nor too tight.

Put the safe silicone cap on the metal probes when not in the use to avoid unnecessary shock.

Charging:**Transmitter:**

DC 5V, 3.7V lithium battery 2000mAh. LED screen will display flashing with “000” when the battery is low. It will need 2-3 hours for fully charge.

Receiver

DC 5V, 3.7V lithium battery 500mAh. LED light will flashing when the battery is low. It will need 1.5 hours for fully charge.

24 Hours Support:

Aweec-service@outlook.com

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules. This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and consider removing the no-collocation statement.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Contact us by e-mail: Aweec-service@outlook.com

A Free Gift will be sent:

LUCKY DOG LESSONS

TRAIN YOUR DOG IN 7 DAYS

BRANDON McMILLAN

LUCKY DOG LESSONS

EMMY® AWARD-WINNING HOST OF
Lucky Dog™

END:
Barking
Begging
Chewing

